




1. Unseal --> unseal_full_access --> enter_cfg_update




2. calibration : read all




3.calibration:cc offset, board offset, temperature




4. calibration: current



5. calibration: voltage




6.read all



The value after calibrated
current

7.change three parameter



8. set battery-id to 4

9.create *.ot.fs , and then program into fg(bq27220) which on my EVM.

10.EVM connect computer via EV2400.

11. check current is incorrect, the other are parameter are ok.

The screenshot shows the 'Data Memory' tab in the bqStudio software. The left sidebar displays device information: EV2400 Version:0.28, I2C, bq27220 0220_0_03 Addr: 0xAA 22.9 degC, 4066 mV, and a voltmeter icon. The main area shows a table of memory contents. Two specific rows are highlighted with red boxes:

Name	Value	Unit
Board Offset	-0.28	mV
Filter	0.2380	-

recover to default value