



- Use the schematic with component values as shown in the datasheet of LM5116 (Reference Design).
- When switching from no load to medium load, LM5116does not provide 5V output, using multimeter it can measure 5V but the backsystem using 5V source of LM5116 doesn't work.
- Vin=12V, Input current = 1.1A, Vout=4.9V, RL=3Ohm, Output current = 1.6A.
- When I removed load (no load), Input current =0.4A, the inductor was quite hot. And repowering 12V, after a short time, the input current will increase again to 0.4A with no load, the inductor will heat up again. Changed the coil and the condition is still not improving.