

# AFE4404 Demonstration Kit

## Message Communication Protocol v4.0



# Message Communication Protocol for AFE4404 EVM

This document describes the message communication protocol for AFE4404 EVM. The message communication protocol applies to AFE4404 EVM with AFE4404EVM GUI version 1.0 or higher.

## Command Format

### 1. Write Register Command

**PC to EVM:** 0x02 <2 bytes of ASCII addr with MSB first> <6 bytes of ASCII data with MSB first> 0x0D  
e.g, to write a value of 0x456789 to address 0x12, message format is  
"0x02 0x31 0x32 0x34 0x35 0x36 0x37 0x38 0x39 0x0D"

| Byte Number | 1                 | 2              | 3              | 4              | 5          | 6          | 7          | 8          | 9              | 10            |
|-------------|-------------------|----------------|----------------|----------------|------------|------------|------------|------------|----------------|---------------|
| Description | Write Reg Command | ASCII addr MSB | ASCII addr LSB | ASCII data MSB | ASCII data | ASCII data | ASCII data | ASCII data | ASCII data LSB | End of packet |
| Payload     | 0x02              | 0x31           | 0x32           | 0x34           | 0x35       | 0x36       | 0x37       | 0x38       | 0x39           | 0x0D          |

The Write Register command is called from the AFE4404 GUI, whenever the user has changed or updated any of the high level controls or modified the register fields in the Low level Configuration in the Device Configuration tab.



### 2. Read Register Command:

**PC to EVM:** 0x03 <2 bytes of ASCII addr with MSB first> 0x0D  
e.g, to read address 0x12, the message format is

| Byte Number | 1                | 2              | 3              | 4             |
|-------------|------------------|----------------|----------------|---------------|
| Description | Read Reg Command | ASCII addr MSB | ASCII addr LSB | End of packet |
| Payload     | 0x03             | 0x31           | 0x32           | 0x0D          |

**EVM to PC:** 0x03 0x02 <3 bytes of raw data with LSB first> 0x03 0x0D  
e.g, if the data read is 0x456789, the message format is

| Byte Number | 1                | 2             | 3            | 4        | 5            | 6           | 7             |
|-------------|------------------|---------------|--------------|----------|--------------|-------------|---------------|
| Description | Read Reg Command | Start of data | Raw data LSB | Raw data | Raw data MSB | End of data | End of packet |
| Payload     | 0x03             | 0x02          | 0x89         | 0x67     | 0x45         | 0x03        | 0x0D          |

The Read Register command is issued from the Low Level Configuration tab of Device Configuration of the AFE4404 GUI when the user clicks on Read Selected  or Read All  buttons. The GUI updates the register map (along with the respective high level control) based on the response from the AFE.

### 3. Start Read ADC Register Command:

**PC to EVM:** 0x01 0x2A <8 ASCII bytes of N packets with MSB first> 0x0D

Example1: to capture 1024 packets, PC sends: "0x01 0x2A 0x30 0x30 0x30 0x30 0x30 0x34 0x30 0x30 0x0D"

Example2: to capture 70000 packets, PC sends: "0x01 0x2A 0x30 0x30 0x30 0x31 0x31 0x31 0x37 0x30 0x0D"

For continuous data, PC sends 0 as the number of the packets.

Example: to capture continuous data, PC sends: "0x01 0x2A 0x30 0x30 0x30 0x30 0x30 0x30 0x30 0x30 0x0D"

EVM sends N packets with each packet having the following format:

**EVM to PC:** 0x01 0x02 <18 bytes of 6 channel data with LSB first> 0x03 0x0D

| Byte Number | 1                          | 2             | 3             | 4         | 5             | 6                | 7            | 8                |
|-------------|----------------------------|---------------|---------------|-----------|---------------|------------------|--------------|------------------|
| Description | Start Read ADC Reg Command | Start of data | LED2 data LSB | LED2 data | LED2 data MSB | LED2AMB data LSB | LED2AMB data | LED2AMB data MSB |
| Payload     | 0x01                       | 0x02          |               |           |               |                  |              |                  |

| Byte Number | 9             | 10        | 11            | 12               | 13           | 14               | 15  | 16  |
|-------------|---------------|-----------|---------------|------------------|--------------|------------------|---|---|
| Description | LED1 data LSB | LED1 data | LED1 data MSB | LED1AMB data LSB | LED1AMB data | LED1AMB data MSB | LED2 – LED2AMB data LSB / Don't care when calibration enabled | LED2 – LED2AMB data / Don't care when calibration enabled |
| Payload     |               |           |               |                  |              |                  |   |   |

| Byte Number | 17  | 18  | 19  | 20  | 21         | 22            |
|-------------|---|---|---|---|------------|---------------|
| Description | LED2 – LED2AMB data MSB / Don't care when calibration enabled | LED1 – LED1AMB data LSB / Don't care when calibration enabled | LED1 – LED1AMB data / Don't care when calibration enabled | LED1 – LED1AMB data MSB / Don't care when calibration enabled | Don't Care | End of packet |
| Payload     |   |   |   |   | XX         | 0x0D          |

The Start Read ADC Register command is issued when the user clicks on the Capture button under ADC Capture & Analysis tab. Depending on the capture mode selected (Finite or Continuous) and the number of samples to capture, the GUI sends the number of data packets to capture. For continuous data, the GUI sends 0 as the number of the packets. Each data packet contains all the 6 ADC result registers along with header and trailer data in the payload.

**Note: The Start Read ADC Register Command assumes that the AFE has been configured correctly to read the ADC result registers.**

#### 4. Stop Read ADC Register Command:

**PC to EVM:** 0x06 0x0D

Note: Clear the USB/ COM port buffer before a Start Read ADC Register command is issued.

| Byte Number | 1                         | 2             |
|-------------|---------------------------|---------------|
| Description | Stop Read ADC Reg Command | End of packet |
| Payload     | 0x06                      | 0x0D          |

The Stop Read ADC register command is issued when the GUI has received the total number of data packets sent during the Start Read ADC register command.

#### 5. Device Identification Command:

**PC to EVM:** 0x04 0x0D

| Byte Number | 1                             | 2             |
|-------------|-------------------------------|---------------|
| Description | Device Identification Command | End of packet |
| Payload     | 0x04                          | 0x0D          |

**AFE4404EVM to PC:** 0x04 0x02 0x34 0x34 0x30 0x34 0x03 0x0D

| Byte Number | 1                             | 2             | 3          | 4          | 5          | 6          | 7           | 8             |
|-------------|-------------------------------|---------------|------------|------------|------------|------------|-------------|---------------|
| Description | Device Identification Command | Start of data | ASCII byte | ASCII byte | ASCII byte | ASCII byte | End of data | End of packet |
| Payload     | 0x04                          | 0x02          | 0x34       | 0x34       | 0x30       | 0x34       | 0x03        | 0x0D          |

When the GUI is started, the Device Identification command is issued by the GUI to identify the EVM connected to the PC. The firmware returns the appropriate response mentioned above. The EVM connected to the PC will be listed in the Global settings tab under Device Configuration.

## 6. Firmware Upgrade Command:

**PC to EVM:** 0x05 0x0D

After the GUI issues the command, the PC invokes user interactive executable to upgrade the firmware.

| Byte Number | 1                        | 2             |
|-------------|--------------------------|---------------|
| Description | Firmware Upgrade Command | End of packet |
| Payload     | 0x05                     | 0x0D          |

The GUI issues the Firmware Upgrade command when the user clicks on **Help** and then **Firmware Upgrade** on the Menu bar. After the GUI issues the command, the PC invokes user interactive executable to upgrade the firmware.

## 7. Firmware Revision Command:

**PC to EVM:** 0x07 0x0D

| Byte Number | 1                         | 2             |
|-------------|---------------------------|---------------|
| Description | Firmware Revision Command | End of packet |
| Payload     | 0x07                      | 0x0D          |

**EVM to PC:** 0x07 0x02 FW\_MAJOR FW\_MINOR 0x03 0x0D

E.g., for rev 1.0, FW\_MAJOR 1  
FW\_MINOR 0

| Byte Number | 1                         | 2             | 3    | 4    | 5           | 6             |
|-------------|---------------------------|---------------|------|------|-------------|---------------|
| Description | Firmware Revision Command | Start of data | byte | byte | End of data | End of packet |
| Payload     | 0x07                      | 0x02          | 0x01 | 0x00 | 0x03        | 0x0D          |

When the GUI is started, the Firmware revision command is issued to identify the firmware revision. The firmware revision will be listed in the Global settings tab under Device Configuration.


## 8. Calibration Enable Command:

**PC to EVM:** 0x08 0x54 0x0D

After the GUI issues the command, the automatic gain calibration routine is invoked in the firmware.

| Byte Number | 1                   | 2                  | 3             |
|-------------|---------------------|--------------------|---------------|
| Description | Calibration Command | Calibration Enable | End of packet |
| Payload     | 0x08                | 0x54               | 0x0D          |

The Calibration Enable command is sent by the GUI when the user checks the Enable Calibration Routine?

 under ADC Capture & Analysis tab.

After the GUI issues the command, the automatic gain calibration routine is initialized and invoked in the firmware waiting for the user input to start capturing the data.


## 9. Calibration Disable Command:

**PC to EVM:** 0x08 0x46 0x0D

After the GUI issues the command, the automatic gain calibration routine is disabled.

| Byte Number | 1                   | 2                   | 3             |
|-------------|---------------------|---------------------|---------------|
| Description | Calibration Command | Calibration Disable | End of packet |
| Payload     | 0x08                | 0x46                | 0x0D          |

The Calibration Disable command is sent by the GUI when the user unchecks the Enable Calibration Routine?

 under ADC Capture & Analysis tab.