

example_emif_sdram.c

This example code configures EMIF module to write and execute from SDRAM

Step 1:

Create a new project.

Navigate: -> File -> New -> Project




Figure: Create a new Project

Step 2:

Configure driver code generation:

Navigate: -> TMS570LCxx /RM5x -> Enable Drivers

- Enable EMIF driver
- Enable GIO driver
- Disable others

Step 3:

Configure pinmux:

- Enable all EMIF pins except EMIF_RNW
- Enable all EMIF outputs including EMIF_CLK

Navigate PINMUX->Pin Muxing

Enable checkbox EMIF and disable EMIF_RNW at ball D17




Figure: Pinmux configuration

Navigate PINMUX->Special Pin Muxing




Figure: Special Pinmux configuration

Step 4:

Configure EMIF

Navigate: -> EMIF -> EMIF General

- Enable EMIF SDRAM
- Disable others

Navigate: -> EMIF -> EMIF SDRAM

- Fill in the timing parameters

EMIF: SDRAM Config			
t (rc or trfc):	63 ns	Max value	427 ns
t (rp):	20 ns	Max value	107 ns
t (rcd):	20 ns	Max value	107 ns
t (wr) or t (rdl):	25 ns	Max value	107 ns
t (ras):	42 ns	Max value	213 ns
t (rc):	63 ns	Max value	213 ns
t (rld):	14 ns	Max value	107 ns
t (xsr):	70 ns	Max value	427 ns
Refresh Period:	64 ms		
Refresh Cycles:	4096		
CAS Latency:	2		
Banks:	4		
Page Size:	elements_256		

Figure: Configuration for ISSI IS42S16400F

Step 5:

Generate code

Navigate: -> File -> Generate Code




Figure: Generate Code

Step 6:

Modify the linker command file

- Add the following under MEMORY
 - SDRAM (RWX) : origin=0x80000000 length=0200000000
- Add the following under SECTIONS
 - .blinky_section : RUN = SDRAM, LOAD = FLASH0 | FLASH1 LOAD_START(BlinkyLoadStart), LOAD_END(BlinkyLoadEnd), LOAD_SIZE (BlinkySize), RUN_START(BlinkyStartAddr), RUN_END(BlinkyEndAddr)

```

10 /*-----*/
11 /* Linker Settings */
12
13 --retain="*(.intvecs)"
14
15 /* USER CODE BEGIN (1) */
16 --retain="*(.blinky_section)"
17 /* USER CODE END */
18
19 /*-----*/
20 /* Memory Map */
21
22 MEMORY
23 {
24 /* USER CODE BEGIN (2) */
25 /* USER CODE END */
26     VECTORS (X) : origin=0x00000000 length=0x00000020
27     FLASH0 (RX) : origin=0x00000020 length=0x001FFFE0
28     FLASH1 (RX) : origin=0x00200000 length=0x00200000
29     STACKS (RW) : origin=0x08000000 length=0x00001500
30     RAM (RW) : origin=0x08001500 length=0x0007EB00
31
32 /* USER CODE BEGIN (3) */
33     SDRAM (RWX) : origin=0x80000000 length=0200000000
34 /* USER CODE END */
35 }
36
37 /* USER CODE BEGIN (4) */
38 /* USER CODE END */
39
40 /*-----*/
41 /* Section Configuration */
42
43 SECTIONS
44 {
45 /* USER CODE BEGIN (5) */
46 /* USER CODE END */
47     .intvecs : {} > VECTORS
48     .text align(8) : {} > FLASH0 | FLASH1
49     .const align(8) : {} > FLASH0 | FLASH1
50     .cinit align(8) : {} > FLASH0 | FLASH1
51     .pinit align(8) : {} > FLASH0 | FLASH1
52     .bss : {} > RAM
53     .data : {} > RAM
54     .sysmem : {} > RAM
55
56
57 /* USER CODE BEGIN (6) */
58     .blinky_section : RUN = SDRAM, LOAD = FLASH0 | FLASH1
59                     LOAD_START(BlinkyLoadStart), LOAD_END(BlinkyLoadEnd), LOAD_SIZE(BlinkySize),
60                     RUN_START(BlinkyStartAddr ), RUN_END(BlinkyEndAddr )
61 /* USER CODE END */
62 }
63

```

Figure: Linker command file

Step 7:

Copy the source code below into your sys_main.c (or) replace sys_main.c with this file.

The example file [example_mibspi_loopback.c](#) can also be found in the examples folder: ../HALCoGen/examples

Note

HALCoGen generates an empty main function in sys_main.c.

```

/*
 * Copyright (C) 2009-2015 Texas Instruments Incorporated - www.ti.com
 *
 * Redistribution and use in source and binary forms, with or without
 * modification, are permitted provided that the following conditions
 * are met:
 *
 * Redistributions of source code must retain the above copyright
 * notice, this list of conditions and the following disclaimer.
 *
 * Redistributions in binary form must reproduce the above copyright
 * notice, this list of conditions and the following disclaimer in the
 * documentation and/or other materials provided with the
 * distribution.
 *
 * Neither the name of Texas Instruments Incorporated nor the names of
 * its contributors may be used to endorse or promote products derived
 * from this software without specific prior written permission.
 *
 * THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS

```

```

* "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT
* LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR
* A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT
* OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL,
* SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES INCLUDING, BUT NOT
* LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE,
* DATA, OR PROFITS; OR BUSINESS INTERRUPTION HOWEVER CAUSED AND ON ANY
* THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT
* INCLUDING NEGLIGENCE OR OTHERWISE ARISING IN ANY WAY OUT OF THE USE
* OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
*/

/* USER CODE BEGIN (0) */
/* USER CODE END */

/* Include Files */

#include "HL_sys_common.h"
#include "HL_system.h"

/* USER CODE BEGIN (1) */
#include "HL_emif.h"
#include "HL_sys_mpu.h"
#include "HL_gio.h"
#include "HL_het.h"
#include "HL_mibspi.h"
/* USER CODE END */

/* USER CODE BEGIN (2) */
#pragma SET_CODE_SECTION(".blinky_section")
void blinky()
{
    int i;
    gpioSetDirection(hetPORT1, 1);
    while(1)
    {
        gpioToggleBit(hetPORT1, 0);
        for(i=0;i<1000000;i++);
    }
}
#pragma SET_CODE_SECTION()

extern uint32 BlinkyLoadStart;
extern uint32 BlinkyLoadEnd;
extern uint32 BlinkySize;
extern uint32 BlinkyStartAddr;
extern uint32 BlinkyEndAddr;
/* USER CODE END */

uint8  emacAddress[6U] = {0xFFU, 0xFFU, 0xFFU, 0xFFU, 0xFFU, 0xFFU};
uint32 emacPhyAddress = 1U;

void main(void)
{
/* USER CODE BEGIN (3) */
    int i;
    uint32 size=(uint32)&BlinkySize;

    emif_SDRAMInit();

    for(i=0;i<size;i++)
    {
        ((char *)&BlinkyStartAddr)[i] = ((char *)&BlinkyLoadStart)[i];
    }

    blinky();
    while(1);
/* USER CODE END */
}

/* USER CODE BEGIN (4) */
/* USER CODE END */

```