

TI Information — Selective Disclosure

DLPC120 Automotive Control Program

User's Guide



Literature Number: DLPU059
March 2018



Contents

Preface	5
1 LED Driver Board Connections	7
1.1 LED Driver Board Connections	7
2 Software Installation and Setup	8
2.1 Software Installation and Setup	8
2.2 Software Components	8
2.3 Automotive Control Program and Total Phase® Cheetah™ Software Installation	8
2.4 Konica Minolta® CA-SDK Installation (Optional)	9
2.5 Piccolo Software	9
3 Quick Start	11
3.1 Quick Start	11
3.2 External Video Troubleshooting	13
3.2.1 Blank screen is displayed on EVM	13
3.2.2 Image is flipped	14
3.2.3 PC resolution is changed when EVM is connected	14
4 Control Program Tabs	15
4.1 Control Program Tabs	15
4.2 Connection	15
4.3 System Configuration	17
4.3.1 Program Piccolo Flash	17
4.3.2 Program ASIC Flash	20
4.4 Calibration and Config File	22
4.4.1 Calibration File	22
4.4.2 Config File	29
4.4.3 Program Calibration Data (Cheetah SPI)	33
4.4.4 Iterative Calibration	34
4.5 System Control	34
4.5.1 Dimming Control	35
4.5.2 Display Mode and Command Lists	38
4.5.3 Temperature Compensation	38
4.5.4 DMD and Heater Control	40
4.6 Utilities	40
4.6.1 Communication	40
4.6.2 Lua Scripting	44
4.6.3 Color/Brightness Characterization	46
4.7 Errors	49
4.7.1 Error Tab	49
4.7.2 ERROR: Timed out waiting for response	50
4.7.3 Device not Available for Use	50
4.7.4 ERROR: Invalid Command	50
4.7.5 Error taking CA-210 Measurement	50
4.7.6 Cal/Config file programming fails	50
5 Reprogramming the EVM	52

www.ti.com

5.1	Reprogramming the EVM	52
5.2	Programming Piccolo Bootloader	52
5.3	Programming Piccolo Main Application	54
5.4	Programming Calibration and Configuration File.....	55
5.5	Programming Application Flash	57

List of Figures

1-1.	LED Driver Board Connections	7
5-1.	Software Reprogramming Flow Chart	52

List of Tables

2-1.	Software Components.....	8
3-1.	Common External Video Issues.....	13
4-1.	Common Errors.....	49
5-1.	Software Reprogramming	52
5-2.	Target Configuration FilesCommon Errors.....	53



Introduction

Trademarks

DLP is a registered trademark of Texas Instruments.
 Konica Minolta is a registered trademark of Konica Minolta.
 Cheetah is a trademark of Total Phase.
 Total Phase is a registered trademark of Total Phase.
 All other trademarks are the property of their respective owners.

Purpose and Scope

This document explains the functionality of the DLPC120 Automotive Control Program. This program is compatible with DLP® technology for automotive head-up display systems using the DLP3030-Q1 chipset.

The DLPC120 Automotive Control Program provides a PC interface to control a DLP3030-Q1 based head-up display (HUD) system. Functionality includes:

- Setting output brightness
- Displaying and modifying an image or test pattern
- Reprogramming configuration and calibration software
- Interfacing with a color meter to measure brightness output and perform calibration

This guide uses the TI DLP3030PGUQ1EVM as an example hardware system, but can be used with any system using the full DLP3030-Q1 chipset.

The following sections are meant for new users:

- LED Driver Board Connections
- Software Requirements and Installation
- Quick Start – Instructions for displaying and dimming an image

The Control Program Tabs section explains the full functionality of the various menus in the Automotive Control Program.

Terms and Abbreviations

Abbreviations	Description
ACP	Automotive Control Program
ASIC	DLPC120 Controller for the DMD
HUD	Head-Up Display
EVM	Evaluation Module

References

The following documents can be found on www.ti.com/mysecuresoftware in the DLP Automotive Head-up Display Documentation and Piccolo Control Software section.

	Document Number	Document Name
1.	DLPU066	DLP3030-Q1 RGB LED Calibration for Automotive Display
2.	DLPU057	DLP3030-Q1 Head-Up Display (HUD) Piccolo SPI User's Guide
3.	2514132	DLPC120 and LED Driver Board Schematics
4.	DLPU064	DLP3030-Q1 Picture Generation Unit EVM DLP3030PGUQ1EVM User's Guide
5.	DLPU061	Piccolo Software Programmer's Guide for the DLPC120 ASIC
6.	DLPA084	LED Driver for DLP3030-Q1 Displays Application Note

LED Driver Board Connections

1.1 LED Driver Board Connections

Figure 1-1 shows the connectors on the DLP HUD LED driver board and all of its connectors. The Piccolo MCU JTAG Connector and SPI Communication connector are used for programming the system. The Type A HDMI connector is used for displaying external video. For instructions on how to connect the LED driver board to the rest of the EVM, please refer to the DLP3030-Q1 Picture Generation Unit EVM DLP3030PGUQ1EVM User's Guide.




Figure 1-1. LED Driver Board Connections

Software Installation and Setup

2.1 Software Installation and Setup

This section describes the software components of the DLP3030PGUQ1EVM and how to download and install them.

Access to www.ti.com/mysecuresoftware is necessary to download software. For login credentials, please contact a TI applications engineer.

2.2 Software Components

Table 2-1 lists all of the software components for the EVM, their location, and their purpose. The following sections explain how to download and install the software.

Table 2-1. Software Components

Software	Location	Purpose
Automotive Control Program and Cheetah™ Drivers	PC	Used to control the EVM.
Piccolo Bootloader	Piccolo Flash Sector A	Allows reprogramming of Piccolo main application via SPI connector.
Piccolo Main Application	Piccolo Flash Sector B+C	Handles DLPC120 initialization routine and dimming commands.
Configuration File	Piccolo Flash Sector D	Defines the functionality available on application flash of the DLPC120.
Calibration File	Piccolo Flash Sector D	Contains look up table used by Piccolo to maintain color point with dimming range.
DLPC120 Application Flash Image	Application Flash	Provides all of the commands necessary for the DLPC120 to perform actions.

2.3 Automotive Control Program and Total Phase® Cheetah™ Software Installation

The Automotive Control Program and Total Phase Cheetah software are necessary to control the EVM. Follow the procedure below to download and install the Automotive Control Program and Total Phase Cheetah Drivers.

Note: The Total Phase Cheetah drivers and cheetah.dll are not distributed by Texas Instruments. Login credentials must be created for www.totalphase.com in order to download the required software.

1. Install Automotive Control Program (ACP).
 - Login to www.ti.com/mysecuresoftware
 - Click “Access” on DLP Auto HUD Gen 1.5 - DLPC120 Automotive Control Program (Object)

Access	DLP Auto HUD Gen 1.5 - DLPC120 Automotive Control Program (Object) View EULA	DLP-AUTO-HUD-GEN1.5-CONTROL-PROGRAM
---------------	---	-------------------------------------

- Download the latest version of the Automotive Control Program (ACP) from the Automotive Control Software Section:

Automotive Control Software						
Software	Release information	Piccolo SW	Bootloader SW	Cal File Format	Revision	Date
Control Program SW	Readme					

- Run setup.exe
 - Follow instructions to completion
2. Install Cheetah drivers.
 - Download and install USB drivers for the Cheetah from: www.totalphase.com/products/usb-drivers-windows
 - **Note:** The installation program should be “Run as administrator” by right-clicking
 3. Download and Copy cheetah.dll.
 - Download Flash Center software from: www.totalphase.com/products/flash-center
 - From the downloaded folder, copy cheetah.dll
 - Paste cheetah.dll file into ACP installation directory:
C:\Program Files (x86)\Texas Instruments\DLPC120 Automotive Control Program 1.4.1.XX
 - This file is used by the ACP and the Total Phase Cheetah to communicate via SPI protocol with the DLP3030PGUQ1EVM.

2.4 Konica Minolta® CA-SDK Installation (Optional)

The Konica Minolta CA-SDK is only necessary for system calibration and color point and brightness analysis. All new EVMs are calibrated before shipping, therefore, this SDK is not necessary for properly displaying an image with the DLP HUD EVM. However, if using a custom hardware and optics design, the system will need calibration for proper operation and a Konica Minolta CA-210 or CA-310 and CA-SDK will be needed.

The CA-SDK can be downloaded from the following link:

www.konicaminolta.com/instruments/download/software/display/ca-sdk/agree.html

2.5 Piccolo Software

Note: The following software is only needed to reprogram the HUD EVM for debug and development purposes. All new EVMs are programmed with the latest Piccolo software before being shipped.

1. Download Piccolo Software.
 - **Note:** Piccolo Software is available in two versions:
 - **Evaluation Software:** Requires click-wrap license. Only binary code. Good for evaluation purposes
 - **Source Code:** Requires signed software license agreement. Good for development and debug purposes.
 - For more details, please contact a TI applications engineer
 - Login to www.ti.com/mysecuresoftware
 - Click “Access” on the appropriate product directory
 - **Evaluation Software:**

Access	DLP Auto HUD Gen 1.5 - DLPC120 Automotive Piccolo Software Application and Bootloader for Evaluation View EULA	DLP-AUTO-HUD-GEN1.5-PICCOLO-SOFTWARE-EVAL
---------------	---	---

- Download DLP HUD Piccolo Software Version 0.21(74) or higher
 - Download DLP HUD Piccolo Bootloader Version 0.1(6) or higher
2. Download and install Code Composer Studio or Uniflash:
- **Uniflash:** TI command line programmer that is used by the Automotive Control Program to program the Piccolo flash.
 - **Download Link:** www.ti.com/tool/uniflash
 - **Code Composer Studio:** Interactive Development Environment (IDE) for Texas Instruments MCUs.
 - Includes uniflash installation
 - Allows user to view and modify Piccolo source code
 - **Download Link:** www.ti.com/tool/ccstudio


Quick Start

3.1 Quick Start


This section explains how to connect a PC to the DLP HUD EVM and display images or videos. For kit assembly instructions, please see the DLP3030-Q1 Combiner HUD EVM DLP3030CHUDQ1EVM User's Guide (DLPU065).

Follow these steps to display an image:


1. Install the Automotive Control Program and Cheetah Drivers as described in [Section 2.3](#) above.
2. Connect an HDMI cable from the PC to the Type A HDMI Connector on the LED Driver Board. See [Chapter 1](#), LED Driver Board Connections to locate the HDMI connector.
3. Connect the Cheetah USB adapter from the PC to the SPI Communication Connector on the LED Driver Board. See [Chapter 1](#), LED Driver Board Connections to locate the SPI connector.
4. Open the Automotive Control Program (ACP).



5. Click Connect as shown in the image above. The "System Not Connected" box will turn to "System On" or the SPI protocol menu shown in Step 6 will be displayed.




6. If the SPI Protocol menu is displayed, select Cheetah SPI. **Note:** This menu is only displayed the first time ACP is used.
7. Click OK.



8. Navigate to System Control > Display Mode and Command Lists from the menu on the left.

9. Select an external video resolution, splash image, or test pattern to display. The EVM is configured to operate with an external video resolution of 864 x 480.
 - **Note:** Please see [Section 3.2](#), External Video Troubleshooting for additional help.



10. Navigate to System Control > Dimming Control.
11. Change Backlight to adjust brightness. Backlight value range is 0 to 65535. Backlight 700 to 1000 is recommended for indoor settings.

3.2 External Video Troubleshooting

This section describes the most common issues with displaying external video and the solutions to those problems. [Table 3-1](#) lists the most common external video issues and the sections with the solutions. For help with issues not described here, please contact a TI applications engineer.


Table 3-1. Common External Video Issues

Section	Error
Section 3.2.1	Blank screen is displayed on EVM
Section 3.2.2	Image is flipped
Section 3.2.3	PC resolution is changed when EVM is connected

3.2.1 Blank screen is displayed on EVM


The most common reasons for a blank image on the EVM are the following:

1. The HDMI cable is not connected properly.
 - **Solution:** Check HDMI connection. Make sure HDMI cable is properly installed in the PC and the EVM.
2. The PC's external monitor setting is in the "Computer Only Mode."
 - **Solution:** Press "Windows + P", then select "Extend" as shown in the image below:



3.2.2 Image is flipped

The HUD EVM contains commands to flip the image. Follow the instructions below to flip the image.




1. From the Automotive Control Program, **press (Ctrl + Alt + M)**, or navigate to **System Control > Display Mode and Command Lists** from the navigation pane on the left side of the window.
2. In the Command Lists section, select Flip from the Type drop-down menu.
3. From the Lists Drop Down menu, select a flip type. The flip is applied immediately when it is selected. Select the one that is appropriate.

3.2.3 PC resolution is changed when EVM is connected

If the PC is trying to duplicate the image on the EVM and the monitor, then the PC resolution can be changed. To fix this, change the PC's external monitor setting to extend:

- Press "Windows + P", then select "Extend" as shown in the image below:




Control Program Tabs

4.1 Control Program Tabs

The Automotive Control Program has several tabs that can be accessed from the left side of the window. The tabs are organized for functionality into the following categories:


- **Connection:** Shows system status and information
- **System Configuration:** Used for programming and calibrating the system
- **Calibration and Configuration file:** Used for viewing, selecting, modifying, and programming calibration and config files
- **System Control:** Used for display, dimming, and other system controls
- **Utilities:** System debug and characterization tools
- **Personalized Tabs:** User created tabs for easy access to functions



The following sections explain each tab in detail.

4.2 Connection

The connection tab controls connection to a HUD EVM, displays information about the status and software of the EVM, and controls connection to a light meter.



The screenshot shows the 'Connection (Ctrl + Alt + C)' application window. It is divided into several panels:

- System Connection (1):** Shows 'TI SPI Protocol - Cheetah' with a status of '-- Connected --'. It includes a 'Disconnect' button and a settings gear icon.
- System On/Off (2):** A green button labeled 'System On'.
- Piccolo-ASIC I2C ClockRate (3):** A dropdown menu currently set to '400 KHz'.
- Light Meter Connection (5):** Shows 'CA210' is 'off'. It indicates 'Not Connected' and offers 'USB' as the connection type. It includes 'Connect', 'Zero Cal', and 'Averaging Mode' (set to 'AUTO') controls. The 'Max Luminance' is set to '999 nits'. Links for 'CA-210 Instruction Manual' and 'CA-210 SDK Download Page' are provided.
- Software Status (4):** Contains a 'Read Status' button and a list of warnings: 'Calibration - Cal File might have been modified', 'Calibration - Config File might have been modified', 'Flash Version - Config File Version Mismatch', and 'SPI - Escape character detected'.
- System Information (6):** Contains a 'Read System Info' button and a table of system details.

Type	Information
Piccolo SW Mode	Application Mode
Piccolo SW Version	0.18(67)
DLPC120 RTL Version	1.0(85)
Cal Format (Piccolo)	0008
Cfg Format (Piccolo)	0008
Cal Data Identifier	609BF385
Cfg Data Identifier	894EBA35
ASIC App Flash Data	894EBA35
ASIC Initialization Type	ODT - OFF
Flash BIST Result	Pass
Flash BIST CheckSum	047F82A2
System BIST Result	Valid
System BIST CheckSum	6FB49910
DMD JTAG BIST Result	Pass
DMD Device ID	0BB1B02F
DDR2 BIST Result	Pass

1. **System Connection:** Displays the connection status of the PC to the Cheetah. Click Connect/Disconnect to connect or disconnect from the Cheetah. Click the settings button to modify protocol.
2. **System ON/OFF:** Shows system state. Click to change state between ON/OFF. State is UNKNOWN when the cheetah or the EVM are disconnected from the PC.
3. **Piccolo-ASIC I2C Clock Rate:** Allows selection of I2C communication rate between Piccolo and DLPC120. Only 400 kHz should be used. **Software Status:** Shows status of the current software. Click "Read Status" to update status.
4. **Software Status:** Shows status of the current software. Click "Read Status" to update status.

5. **Light Meter Connection:** Click Connect to connect to the CA-210 or other compatible light meters.
 - **Averaging Mode:** Determines how many measurements the CA-210 takes internally. AUTO setting is recommended.
 - **Max Luminance:** Maximum brightness allowed by the light meter.
6. **System Information:** Lists system software versions and Built-In Self-Test (BIST) results. Click “Read System Info” to update.

4.3 System Configuration

The system configuration tab is used to load software onto a DLP HUD EVM. The Piccolo and the DLPC120 Application Flash can be programmed from this menu.


4.3.1 Program Piccolo Flash

The tabs in this section are used for programming the Piccolo flash using SPI or JTAG. The bootloader must be programmed using JTAG as described in [Section 5.2](#), Programming Piccolo Bootloader. The Piccolo Main application can be programmed using JTAG or it can be programmed using SPI as described in [Section 5.3](#), Programming Piccolo Main Application. Programming the Piccolo main application using SPI is recommended.

4.3.1.1 Program Piccolo SW—Cheetah SPI

This tab allows the user to program the Piccolo's main application as shown in [Section 5.3](#). The main application is provided in a (.hex) format in the Debug directory of the Piccolo main application project on www.ti.com/mysecuresoftware. See [Section 2.5](#) for help with downloading the Piccolo software.

The Piccolo main application can be loaded using this menu only if the bootloader is already loaded on the system, and the system is in bootloader mode. The bootloader can be loaded using JTAG as shown in [Section 5.2](#). The system can be changed to bootloader mode using this menu.



1 Bootloader Settings File:
Browse C:\Program Files (x86)\Texas Instruments-DLP\Automotive Control Program 1.3.0.40\Settings\Xmls\BootloaderSettings.xml

2 Piccolo Main Application (.hex file):
Browse C:\Users\A0221326\Downloads\HUD_Piccolo_SW_Release_V0.18(67)\Application Code Binary\Piccolo_TMS320F28023_Application

3 Bootloader Mode Get Mode Toggle Mode

4 Program

5 Settings
Flash Erase wait time (per sector) 2.0 sec
Packet Size 127 words

Tip:
If the Piccolo does not switch to bootloader mode when "Toggle Mode" is clicked, you can attempt resetting the board. This should be done while "Toggle Mode" is running.

This page allows you to program the Piccolo Application Software to Piccolo Internal Flash Memory using the help of bootloader software. A valid bootloader should be present in Piccolo flash to perform this operation.

The system should be connected as shown in the diagram.

Steps to Program:

1. Load the Bootloader XML (if not already loaded).
2. Load the Piccolo Main Application.
3. If the current mode is "Application Mode" or "Unknown Mode", click "Toggle Mode" to bring it in "Bootloader Mode". If already in "Bootloader Mode", skip this step.
4. After the current mode is switched to "Bootloader Mode", programming is enabled.
5. Click "Program" to program the Flash.
6. To go to the Application, click "Toggle Mode".

USB cable

Piccolo MCU

1. **Bootloader Settings File:** Stores settings required to program the Piccolo. Default file is provided with Automotive Control Program. Do not modify unless required.
2. **Piccolo Main Application (.hex):** Piccolo Main Application. Provided with Piccolo Main Application software release on www.ti.com/mysecuresoftware. Click Browse to select file for programming
3. **System mode and State:** Displays and changes state of the system between Bootloader and Application Mode.
 - **Bootloader Mode:** Allows update of Piccolo main application via SPI
 - **Application Mode:** Normal operation mode for EVM
 - **Get Mode:** gets the updated status of the system mode
 - **Toggle Mode:** used to switch between bootlader mode and application mode
4. **Program:** Click to program selected Piccolo Main Application to EVM.
5. **Settings:** Piccolo programming settings.
 - **Flash Erase Wait Time:** wait time between erase of each Piccolo flash sector
 - **Packet Size:** size of packets written to Piccolo Flash

4.3.1.2 Program Piccolo SW—JTAG, Uniflash

This page allows programming the Piccolo Flash—bootloader or main application—using a JTAG emulator and Uniflash as shown in [Section 5.2](#).

Uniflash is a command line programmer for TI target devices. It is part of the Code Composer Studio installations for versions 5.4 or higher. It is also available for free from the following location:

- **Uniflash Download Link:** www.ti.com/tool/uniflash

The screenshot shows the 'System Configuration > Programming - Piccolo Flash > Program Piccolo SW (JTAG, UniFlash) (Ctrl + Alt + U)' window. It includes a 'Program' tab and a 'Settings' tab. The 'Program' section contains three file selection fields: 'Target Config File (ccxml)' pointing to a path in the workspace, 'Uniflash.bat Executable' pointing to the command line programmer, and 'Piccolo .out file' pointing to the compiled C code. A 'Start Programming' button is located below these fields. Below the 'Program' section is a 'Command Line log' area. A diagram illustrates the hardware setup: a laptop connected to a Piccolo MCU via a JTAG cable.


1. **Program:** Section for selecting the files used to program the Piccolo flash and to program the Piccolo flash.
 - **Target Config File:** File that specifies which JTAG emulator is being used for programming the Piccolo. Two files are provided with the Piccolo software projects—one for XDS100 and one for XDS510.
 - **Uniflash.bat Executable:** TI command line programmer executable. Provided with Code Composer Studio version 5.4 or higher. Also available as standalone tool from www.ti.com/tool/uniflash.
 - **Piccolo.out File:** Compiled C code for Piccolo bootloader or main application. Provided in Debug directory of software project
2. **Command Line Log:** Log to display programming log. Used for debug purposes if necessary.

System Configuration > Programming - Piccolo Flash > Program Piccolo SW (JTAG, UniFlash) (Ctrl + Alt + U)

This page allows you to program Piccolo software using UniFlash which is a command line Programmer for TI Targets. UniFlash is part of Code Composer Studio installation from version 5.4 onwards.

You can also get this tool free of charge from TI website mentioned below:
<http://www.ti.com/tool/uniflash>

Please connect the system as shown in the diagram.



Program Settings

Sectors to Erase

<input checked="" type="checkbox"/> Sector A	3
<input checked="" type="checkbox"/> Sector B	
<input checked="" type="checkbox"/> Sector C	
<input type="checkbox"/> Sector D	


3. **Sectors to Erase:** Determines which sectors to erase before programming:

- **Sector A:** Bootloader
- **Sector B and C:** Piccolo Main Application
- **Sector D:** Piccolo Calibration and Configuration file

4.3.2 Program ASIC Flash

This tab allows programming the SPI Application Flash on the EVM as shown in [Section 5.5](#).

To program the application flash, the Cheetah SPI adapter needs a direct connection to the application flash. This can be done on the EVM by clicking the Switch SPI bus button on this page. This disconnects the Cheetah from the Piccolo and connects it to the application flash. **Note:** The EVM must be restarted to reconnect to the Piccolo.




1. Browse and select config or flash binary file.
2. SPI flash mode indicator.
3. Actions for SPI flash memory.
4. **Target Flash Device Information:** Used for selecting, detecting, and viewing information about the target SPI flash.
 - **Target Device:** Drop Down menu to select from list of flash devices
 - **Auto Detect:** Click to automatically detect flash device
 - **Load Parts File:** Click to Load Flash device XML if Auto Detect cannot successfully detect the part
 - **Selected Device Information:** Information about the selected flash device
 1. **Override Max Bit Rate:** Click to manually set Max Bit Rate
 2. **Advanced>> / << Button:** Click to switch between Advanced and Simple view of flash device information.
5. **Binary View:** Displays binary data of selected file.

4.4 Calibration and Config File


The calibration (cal) and configuration (config or .cfg) file are stored in the Piccolo's flash in sector D. The config file contains data about the system's capabilities, such as its display modes. The cal file contains information used for dimming.

This section allows browsing, editing, and programming of the cal and config file as shown in [Section 5.4](#). The calibration wizard can be used to generate a new cal file. See the DLP HUD Calibration Guide to learn how to generate a new calibration file.


4.4.1 Calibration File




1. **Browse:** Click to open a saved calibration file.
2. **Recent Calibration Files:** Click a file name to open a recently saved cal file.



3. **Read Only View:** Shows contents of the opened calibration file in a read-only view.
4. **Print/Print Preview:** Click to print or preview a printed cal file.
5. **Contents:** Click Links to jump to content in the cal file.



6. **File Creation Details:** This tab shows information about how and when the cal file was generated.
7. **Calibration ID:** This ID is automatically generated when the cal file is created. It needs to be updated when changes are made to the cal file. Click “Generate” to update.



Calibration File: C:\Users\A0221326\Documents\Training\Example_Output.cal

Buttons: Browse, Save As, Verify, Close, Show Additional Information

Read-Only View | File Creation Details | **Defaults** | Calibration Tables | Other | Charts | Binary Data | Log File | 0 Errors / 0 Warnings

Defaults

Backlight: 32768

Base Temperature: 25 C

PWM Period: 1200

Master ON:

Feature Enable/Disable

Temperature Compensation

VAC

Voltage Monitoring

Default Dimming LUT/CMT


Dimming LUT Index: 0

CMT ID: 0


Note: The default Dimming LUT group is automatically populated by Auto-Cal. Selecting a different Dimming LUT can cause non-linear dimming and wrong white-points.

Note: Command Lists to run during startup can be selected in the config file defaults page.


8. **Defaults Tab:** This Tab is used to set the default settings of the cal file. These settings are used by the EVM at startup if the calibration file is programmed on it.
9. **Defaults Section:** Sets the initial system state at power-on.
 - **Backlight:** Default brightness of the system (0-65535)
 - **Base Temperature:** Temperature table to be used if temperature compensation is disabled
 - **PWM Period:** Period of PWMs used to generate LED target levels
 - **Master ON:** Determines if system should start up in Master On/Off mode
10. **Feature Enable/Disable:**
 - **Temperature Compensation:** Adjusts LED PWMs based on temperature. Only recommended if system has been calibrated across operating temperature range.
 - **VAC:** Digital Dimming function for use at low brightness levels. The backlight value for VAC enable is defined in the calibration tables
 - **Voltage Monitoring:** Turn on/off voltage monitoring at startup.
11. **Default Dimming LUT/CMT:** This section selects the default dimming table and gamma to use. This section is automatically populated by calibration.




12. **Calibration Tables:** This tab shows calibration look up tables used by the Piccolo to set LED PWMs. Calibration temperatures for all temperatures can be viewed from this tab.
13. **Temperature Data:**
 - **Temperature:** Lists all the temperatures for which calibration tables are stored
 - **VAC Mode Switch Backlight:** Sets backlight at which digital dimming should be used if enabled
 - **Calibrated:** Shows whether the stored calibration data was generated from a calibration procedure or not
14. **Add Transition Temperature:** Adds all necessary tables for transition temperatures if they are not already present in the cal file. **Note:** This is needed for DLP3030-Q1 operation.
15. **Calibration Data for Selected Temperature:** Dimming table for the selected temperature.
16. **Show additional information:** Displays informational auto-calibration results in the calibration table, such as calibration targets and errors.




17. Right Click the rows in the calibration tables or the temperature table for additional options.




18. **Other:** Input the photodiode sensor gains available on the LED driver. TI EVM has 1x, 4x, 8x, and 16x.




19. **Charts:** This menu creates various plots for the data in the calibration file.
20. Select the plot to display.
21. Select the temperatures, backlight value range and scale to display.



22. **Binary Data:** Click “View Cal Binary Data” to view the binary data stored in the cal file.



23. This page shows the calibration log if it is available in the cal file’s directory with the same name as the cal file.




24. **Errors/Warnings:** This page shows any errors or warning in the cal file.


4.4.2 Config File




1. **Browse:** Click to open a saved config file.
2. **Recent Calibration Files:** Click a file name to open a recently saved config file.




3. **Read Only View:** Shows contents of the opened config file in a read-only view.
4. **Print/Print Preview:** Click to print or preview a printed config file.
5. **Contents:** Click the links to jump to content in the config file.



6. **Defaults:** This tab is for viewing and modifying the command lists that are run at startup. See [Section 4.4.2.1, Modifying Default Command Lists](#) for instructions.
7. Click buttons to add, delete, or reorder commands lists to be run at startup. Command lists are run in order from top to bottom.
8. Shows the command lists that will be run at startup. Command lists are run in order from top to bottom.



9. **Errors/Warnings:** This tab shows the Errors and Warnings in the config file.




10. The DLPC120 App Flash data can be viewed and saved from this tab. Click View ASIC Flash Data or Save ASIC Flash file to view or save the flash data.

11. Click Program ASIC Flash to jump to ASIC Flash Programming tab .


4.4.2.1 Modifying Default Command Lists

This section shows how to select which command lists to run at start-up.


To add a new command list, navigate to the **Defaults** page on the **Calibration and Config File>Config File** tab. Then, follow these steps:




1. Click Button to add Command List.



2. Select the command list(s) to run at start-up.
3. Click OK.



4. Select Command lists and use arrows to reorder as desired. Command lists are run in order from top to bottom.




5. Click Verify to check for errors. Errors and Warning will be displayed in the Error/Warnings tab.
6. Click Save or Save As to Save file.
7. Program calibration and config file as shown in [Section 5.4](#).
 - **Note:** Updating DLPC120 App. Flash is not required.


4.4.3 Program Calibration Data (Cheetah SPI)

This tab has the following functions:


- Programming the selected cal and config file to the EVM. See [Section 5.4](#) for more details.
- Viewing the Memory Map of the calibration data
- Changing Programming settings
- Viewing Calibration Binary
- Viewing DLPC120 Flash Build Information




1. Click Verify and Program to program selected calibration and configuration file to Piccolo.




2. This tab is for checking the memory map of the combined calibration and the configuration data.



3. Adjust the programming settings from this section. If the wait time is too short, programming may fail.
4. Shows Approximate time to Program based on settings.



5. Click Read Cal Data from Piccolo to read the data currently stored on the EVM.



6. Click to read information about the DLPC120 Flash build stored within the config file.

4.4.4 Iterative Calibration

Use of the calibration procedure is described in DLP3030-Q1 RGB LED Calibration for Automotive Display (DLPU059).

4.5 System Control


This section of the ACP is used for controlling the EVM. It is divided into the following sections:

- **Dimming Control:** Change the brightness level of the system and take measurements with a light

meter

- **Display Mode and Command Lists:** Change Display Modes or run commands lists from the config file
- **Temperature Compensation:** Read DMD temperature, enable/disable temperature compensation, modify TMP411 parameters
- **DMD and Heater Control:** Modify DMD drive strength and DMD heater PWM parameters

4.5.1 Dimming Control




1. **Dimming Control:** This section is used to control the brightness of the EVM. It allows control of individual LEDs or all LEDs at once.
2. **Color Point Measurements:** This section works with a light meter to provide color point and brightness measurements in the CIE 1931 color space. Light meters compatible with the Konica Minolta CA-210 SDK are supported.

4.5.1.1 Dimming—Normal and Calibration Mode

The dimming of the EVM can be controlled in two modes:


- **Normal Mode:** Used for normal operation. LEDs, DMD sequence, and sensor gain are automatically adjusted based on backlight value and the currently programmed calibration data.
- **Calibration Mode:** Used for debugging/calibration purposes. Allows independent control of LEDs, DMD sequence, and sensor gain.



The mode can be controlled from the System Mode drop-down menu.

4.5.1.1.1 Normal Mode


In Normal Mode, input a backlight value (0 – 65535) to adjust the system brightness. Individual LEDs, sequences, and sensor gain will automatically adjust based on the backlight value. The calibration file stored on the system is used to determine individual LED levels.



1. **Backlight:** Backlight value range is 0 to 65535. Dimming Parameters are determined by Backlight value.
2. Click **Set** or press “Enter” to update Dimming Parameters based on Backlight value.
3. Click **Get** to view the system’s current backlight value and Dimming Parameters.

4.5.1.1.2 Calibration Mode


In calibration, the Dimming Parameters can be individually adjusted.



1. **Dimming Parameters:** system parameters that affect brightness and color point.
 1. **PWMs:** Target levels for the LEDs and Current Limit:
 1. **Red/Green/Blue:** Optical feedback level for LEDs. Enter value from **0 to 59418**
 2. **Current Limit:** Sets current limit for LEDs. **0 to 61166**
 2. **Sensor Gain:** Determines gain on the photo feedback sensor circuit. Higher gain results in lower brightness.
 3. **LDC Index:** Determines LED and DMD duty cycle and operation Mode. In general, lower LDC results in higher brightness.
2. Click **Set** or press “Enter” to apply the Dimming Parameters.
3. Click **Get** to update the system’s Dimming Parameters.

4.5.1.2 Brightness and Color Point Measurements


The Color Point Measurements section is used for measuring system brightness and color point.



1. Click New Connection to Connect to the light meter.
2. Click **Measure**, **Save**, or **Clear** to take, save, clear measurements.
3. **Measurement Results:** Shows measurement results:
 1. **Normal/Calibration Mode:** Shows the mode in which the measurement was taken.
 2. **Red/Green/Blue:** Shows the PWM of the LEDs when the measurement was taken.
 3. **Y/x/y:** CIE 1931 brightness and color point measurements.
 4. **LDC Index:** LDC index of measurement.
 5. **Gain:** Optical Feedback Gain.

4.5.2 Display Mode and Command Lists


This tab changes the display mode of the system and also runs various other command lists that are available in the config file.



1. Click **Refresh Available Lists** to read the command list data stored on the connected Piccolo and update the drop down menus on the page.
2. **Display Mode:** Menus to select the display mode.
 1. **External Video:** Select resolution from drop down menu to put system in external video mode and display selected resolution.
 2. **Splash:** Select an image from the config file to display.
 3. **Test Pattern:** Select a test pattern from the DLPC120 to display.
3. **Sequence Table and Gamma Selection:** Change the sequence table or Gamma.
 1. **Note:** This section is only available in Calibration Mode. The gamma or sequence update is not completed until the system is changed back to normal mode. Change the system mode from System Control > Dimming Control tab.
4. **Command Lists:** Runs commands from the config file.
 1. **Type:** Select command list category first. Example: Flip, or Dither.
 2. **Lists:** Select the command list to run. The command list is run immediately when it is selected.
5. **Bezel Offset:** Adjust image location on the DMD.
 1. **Vertical Offset:** Image vertical position adjustment.
 2. **Horizontal Offset:** Image horizontal position adjustment.


4.5.3 Temperature Compensation

This tab controls the temperature compensation parameters used by the Piccolo software. For an explanation how temperature compensation works, see Piccolo Software Programmer's Guide for the DLPC120 ASIC (DLPU061).



1. **Enable Compensation:** Determines whether LED PWMs should be adjusted based on temperature or not.
2. **Temperature used for Compensation:** Displays the temperature that is currently being used for temperature compensation.
3. **Low Pass Filter Coefficients:** Software low pass filter coefficients that can be used for temperature compensation.
4. **Measurement Mode:**
 1. **User Selected Temperature:** Allows user to set system temperature used by the Piccolo in order to set LED PWMs. For Debug purposes only.
 2. **DMD temperature measured via TMP411:** Makes Piccolo software use measured DMD temperature.
 1. **Measurement Frequency:** Rate for Piccolo software to read DMD temperature from TMP411.
5. **DMD Array Temperature:** DMD temperature from TMP411. Click Get to update.

4.5.4 DMD and Heater Control



1. **DMD Drive Strength:** Select the drive strength of the DMD from the drop-down menu.
2. **Heater PWM Control:** Select Frequency and Duty Cycle of DMD Heater PWM. **Note:** Use of the heater is not needed for full operation. The DLP3030-Q1 DMD will function without the heater enabled over the full -40°C to 105°C operating temperature range. Duty cycle should be left at 0%.

4.6 Utilities


This section of the ACP contains utilities for debug and characterization purposes.

4.6.1 Communication

These tabs are used for communicating with the EVM.


4.6.1.1 ASIC Registers

This section allows the user to write values directly to DLPC120 registers. A list of all available DLPC120 registers can be found in the Help menu. Press Ctrl + F1 to display the help menu.



1. **Register Read/Write:** Set or get ASIC register value:
 1. **Get:** Type ASIC Register address into Address, then press Get.


2. **Set:** Type ASIC Address and Data, then press Set.
2. **Smart Edit:** This field lets you read/write individual register fields. Press Set after editing field to update register.
 - **Bits:** Shows the bits of the register for the specified field
 - **Value:** Value of the bit field
 - **Description:** Description of the bit field
 - **Reset:** Default value at DLPC120 reset



3. **Register Dumps:** View/Save the register actions.

4.6.1.2 Piccolo SPI Command


This section is for sending raw SPI commands to the EVM and then reading the response of the EVM. It can be used for debugging or learning purposes.



1. **Command ID + Read:** Enter the ID of the command and select whether it is a read or write command. See DLP3030-Q1 Head-Up Display (HUD) Piccolo SPI User's Guide (DLPU057) for more information.
2. **Length/Read Length:** Specifies the length or the read or write command automatically.
3. **Data:** Input data to send here. One byte per line.
4. **Read Data:** Displays the data read from the system in case of a read command.
5. Click **Send** to send command.
6. **Response:** Displays system response to SPI command.

4.6.1.3 SPI Command Log

This section of the ACP is for viewing a log of the SPI commands.




1. Logging Options:

- **Log to File:** Determines whether SPI commands should be stored in a log file
- **Log to Screen:** Determines if SPI commands should be displayed in the Log tab

2. Click **Browse** to select a log file.

3. **Log:** shows the SPI commands that have been sent if the Log to Screen option is selected.



4. Click to Decode the log that is selected in the **Decode data source** section.

5. Select which log to decode.

6. Filter data to decode by time.

Utilities > Communication > SPI Command Log (Ctrl + Alt + S)

Log to File SPI_Command_Log_2015_01_14.log

Log to Screen

No	Time	Command Name	Cmd ID	Type	Tx Len	Response	Rx Len	Num Bytes taken for Response
13	1/14/2015 11:04:40 AM	BIST Results	0x30	Read	0	Success (0x01)	13	45 0A CE C9 0C 0C 0C 1 0C 0C 0C BC 83 B4 6F
14	1/14/2015 11:04:40 AM	Calibration Data Version	0x6F	Read	0	Success (0x01)	8	75 10 0E 42 1 CC 33 01 BE C7

7. Decoded SPI commands.


4.6.2 Lua Scripting

This section is used to write and execute scripts in order to automate system functions.


The scripting language used for this section is Lua 5.1. To learn more about Lua, visit:

- www.lua.org/start.html
- www.lua.org/manual/5.1


The ACP includes many DLP HUD specific Lua functions. These are described in the Help section of the Lua Scripting tab as shown in step 12 below.



1. Click to **Open** script file.
2. Click to **Refresh** script file.
3. Click to **Close** script file.
4. Click to **Save** script. Click drop down menu to **Save As** or **Save Log**.
5. Click to **Clear Script**.
6. **Play, Pause, or Stop** script execution.
7. Displays script execution state and line no.
8. Enable GUI updates during execution—highlights code lines during execution.
9. **Script Editor**: write/edit scripts here.
10. **Script Log**: Errors and printed messages are displayed here.



11. **Recent Files:** Shows recent Lua files.



12. **Help:** Shows HUD specific Lua functions. Click any function to see example code.

4.6.3 Color/Brightness Characterization

The tabs in this section are used for characterizing the systems color and brightness.

4.6.3.1 Dimming Characterization

This section is used to measure the brightness of the system as the backlight value is changed.

4.6.3.2 LED Characteristics


This tab is used to create plots of LED Brightness vs PWM. It can be used for debugging and calibration purposes.

The screenshot shows the 'LED Characteristics' utility window. It includes tabs for 'Settings', 'LED Curve', 'Red LED Data', 'Green LED Data', and 'Blue LED Data'. The 'Settings' tab is active and contains several sections:

- Measurement Settings:** Includes 'Delay between measurements (in ms)' (set to 50), 'Filter transmission percentage', 'LDC Index' (set to 0), 'Sensor Gain' (set to 1x), and 'Current Limit' (set to 56.797).
- Light Meter:** A dropdown menu and a 'New Connection' button.
- Buttons:** 'Load' and 'Save' buttons.
- Table:** A table with columns: Enable, Color, From (Min), To (Max), Increment, Fine Increment, Weighted?, Num Weighted Points, and Maximum difference in Slope. It lists settings for Red, Green, and Blue LEDs.
- Measurements:** 'Load' and 'Save' buttons.
- Plot Characteristics:** 'Start' and 'Stop' buttons.
- Operating Range Result:** A table with columns: Color, Min PWM, Max PWM, and Range.
- Compute Operating Range:** 'Start', 'Stop', and 'Positive Slope Method' (dropdown) buttons.

1. **Delay Between Measurements:** Delay in between the measurements taken by the CA-210.
2. **ND Filter percentage**
3. **LED / Image settings:** Settings for image when taking measurements.
 - **LDC Index:** LED sequence and operation mode to be measured
 - **Sensor gain:** optical feedback amplifier gain
 - **Current Limit:** LED driver current limit
 - **Use user pattern setup:** Uses image displayed by user. Otherwise, a white pattern is used.
4. **Light Meter:** Connect to a light meter.
5. **Load/Save:** Load or Save measurement settings.
6. **PWM settings:**
 - **Enable:** Select whether to measure an LED or not
 - **From:** minimum PWM to measure
 - **To:** Max PWM to measure
 - **Increment:** Increment between PWM values
 - **Fine Increment:** For development use only. Set to 50.

- **Weighted:** For development use only. Do not check.
 - **Num Points weighted:** For development use only
 - **Max Difference in slope:** For development use only
7. **Load / Save Measurements:** Load or Save measurement results.
 8. **Plot Characteristics:** Click to start measuring and plotting data.
 9. **Operating Range Result:** Determines max and min usable PWM. This feature is still under test.
 10. **Compute Operating range:** Computes operating range from data. This feature is still under test.



11. **LED Curve:** This page shows the measured LED Brightness vs PWM data.
12. **Curves to view:** Select which LED's data to view and whether to view weighted data or raw data.
13. Select the grid lines to display.
14. **LED Data:** LED data. Click and drag to zoom in.
15. Click here to zoom out.

No	PWM	CIE Y	CIE x	CIE y	CIE z
0		0	0.0032	0.3506	0.4262
1	1000		0.0032	0.3735	0.3802
2	2000		0.3068	0.6469	0.3531
3	3000		0.3794	0.6477	0.3523
4	4000		0.4559	0.6479	0.3521
5	5000		0.5244	0.6482	0.3518
6	6000		0.5999	0.6481	0.3519
7	7000		0.6784	0.6481	0.3519
8	8000		0.7570	0.6486	0.3514
9	9000		0.8377	0.6486	0.3514
10	10000		0.9183	0.6487	0.3513

16. **Red/Green/Blue LED Data:** This section shows the measured LED data in table form.

4.7 Errors

This section describes the error tab and common errors. [Section 4.7.1](#) describes the Error Tab and its functionality. **Error! Reference source not found.** shows common errors and the section they are described in.

Table 4-1. Common Errors

Section	Error
6.6.2	ERROR: Timed out waiting for response
6.6.3	Device not Available for Use
6.6.4	ERROR: Invalid Command
6.6.5	Error taking CA-210 Measurement
6.6.6	Cal/Config file programming fails

4.7.1 Error Tab

The error tab is located at the bottom of the ACP window. Its functionality described below.

No.	Timestamp	Error Description
1	2/12/2015 7:10:55 PM	Error taking CA210 Measurement! SDK Command Error --measurement fail --check probe/display_setting

1. Select whether the error menu should be shown when an error occurs.
2. Click to hide the error menu. **Warning:** If “Display when Error Occurs” is deselected, the error menu will not pop when an error occurs after it is hidden.

3. Clear currently displayed errors.
4. Error timestamp and description.
5. Click here to display error menu when it is hidden.

4.7.2 ERROR: Timed out waiting for response

This error occurs because the connection to the HUD EVM was lost. This could be for several reasons:

- The Cheetah is not connected to the EVM
- The PC entered sleep mode
- The EVM was restarted

Follow these steps to resolve the error:

1. Make sure the Cheetah is connected on the EVM.
2. Make sure the EVM is powered up.
3. From the Connection tab Click Disconnect and then press Connect.

4.7.3 Device not Available for Use

This error occurs because there are multiple ACP windows open or another program is trying to use the Cheetah. Close any additional ACP windows and any other applications that are trying to use the Cheetah.

4.7.4 ERROR: Invalid Command

This error occurs because the command sent by Automotive Control Program was not recognized by the EVM.

The SPI command may not be in the Piccolo software for the following reasons:

1. Piccolo software is old and does not contain SPI command handler.
2. ACP is old. Command is no longer included in Piccolo Software.

4.7.5 Error taking CA-210 Measurement

This error occurs when the brightness is too high for the CA-210 to measure. To fix this error add an ND filter in front of the CA-210 probe, or move the CA-210 probe further away from the light source.

4.7.6 Cal/Config file programming fails

This error can occur because the wait time between the writes of the flash sectors is too short. Increase this setting from the Calibration and Config File > Program Calibration Data tab as shown below:

Calibration and Config File > Program Calibration Data

Verify and Program

This page allows you to program the loaded calibration/config data to Piccolo. The system should be connected as shown in the diagram.

Memory Map Settings Calibration Binary ASIC Flash Build Information

Settings

Flash Erase wait time (per sector) 2.0 sec

Approx time to Program 00:00:08

Packet Size 127 words

Reprogramming the EVM

5.1 Reprogramming the EVM

This section explains how to reprogram the DLP HUD EVM. All new EVMs are programmed, and do not need to be reprogrammed until a new software release becomes available in the future. EVMs sold with optics are also calibrated.

EVMs may need to be reprogrammed for evaluation and debug purposes. [Table 5-1](#) describes the protocol and reasons for reprogramming any software on the EVM.

Table 5-1. Software Reprogramming


Software	Programming Protocol	Reason for reprogramming
Piccolo Bootloader	JTAG	The bootloader will not require frequent updates. It may need to be updated if bugs are found in the current version or additional functionality is added.
Piccolo Main Application	SPI (with bootlader) JTAG	TI provides occasional new releases of Piccolo main application for added functionality.
Configuration File	SPI	Can be updated to reconfigure system capabilities such as test patterns, splash images, video resolutions, and DMD sequences. Contact TI applications engineer for new configuration file.
Calibration File	SPI	Needs to be updated when system is recalibrated.
DLPC120 Application Flash	SPI	Needs to be updated at the same time as Configuration file

[Figure 5-1](#) shows the recommended software reprogramming flow chart. Not all steps of this reprogramming need to be completed. To determine when software needs to be reprogrammed, refer to [Table 5-1](#). Reprogramming does not need to be done in the following order. However, the recommended order is the most time efficient way to reprogram software. Please make sure that all the software installation is complete before beginning this procedure.



Figure 5-1. Software Reprogramming Flow Chart


5.2 Programming Piccolo Bootloader




The bootloader allows the main application of the Piccolo to be programmed using the Piccolo SPI connector. It will very rarely need to be upgraded.

This section requires an XDS100 or XDS510LC USB to JTAG emulator.

Follow these instructions to program the bootloader:



1. From the navigation pane, go to System Configuration > Programming–Piccolo Flash > Program Piccolo SW (JTAG, UniFlash).
2. Switch to Settings Tab and select sectors A, B, and C to erase.
 - Selecting sector D will also erase the calibration and configuration data that are currently stored in the Piccolo Flash.




3. Connect an XDS100v2 or XDS510lc to a USB port on the PC and the JTAG connector, H1, on the HUD EVM LED Driver board.
4. Load the correct target configuration file:
 - Target configuration files are included in the bootloader software project in the following location:
 - \HUD_Piccolo_Bootloader_SW_Release_V0.1(6)\Target Config Files\
 - The Piccolo SW project comes with two target configuration files as shown in [Table 5-2](#)

Table 5-2. Target Configuration Files Common Errors


Programming Device	Target Configuration File
XDS510LC	XDS510LC_F28023.ccxml
XDS100	XDS100_F28023.ccxml

5. Load Uniflash.bat file. Included in the following location if Code Composer Studio is installed:
 - **Location:** <CCS Installation path>\ ccs_base\scripting\examples\uniflash\cmdLine\uniflash.bat
6. Load Piccolo Bootloader .out file:
 - **Location:** \HUD_Piccolo_Bootloader_SW_Release_V0.1(6)\Bootloader Code Binary\
7. Click “Start Programming.”

8. When complete, the following prompt will be displayed. Click “OK.”



5.3 Programming Piccolo Main Application




The main application of the Piccolo controls initialization, communication with the external host and the ASIC, and dimming. This section describes how to program the main application using SPI.

This section requires the Total Phase Cheetah and the SPI adapter cable included with the EVM.

Follow these instructions to program the main application of the Piccolo:




1. Connect Cheetah Adapter to USB port on PC and SPI connector, J10, on the EVM.
2. Navigate to Program Piccolo SW (Cheetah SPI).




3. Under Bootloader Settings File, click Browse and select Bootloader Settings file.
 - **Default location:** C:\Program Files (x86)\Texas Instruments\DLPC120 Automotive Control Program 1.4.1.XX\Settings\Xmls\BootloaderSettings.xml
4. Under Piccolo Main Application, click Browse and select main application (.hex) file:
 - **Default location:** \HUD_Piccolo_SW_Release_V0.18(67)\Application Code Binary\

5. Click Program.
6. When complete, click close on the prompt window shown below:



7. Reset the system by turning the power “off” and then “on” again. The system will be in application mode when it restarts.


5.4 Programming Calibration and Configuration File




The configuration file informs the Piccolo about the commands available in the application flash memory and their addresses. The calibration file contains the look-up tables used by the Piccolo to perform dimming operations.

The calibration and configuration file are programmed into sector D of the Piccolo as a combined binary. For more details, see the Piccolo Software Programmer’s Guide for the DLPC120 ASIC (DLPU061).

This section describes how to program the calibration and configuration file using SPI:




1. Navigate to Calibration and Config File > Calibration File.
2. Browse and select a calibration file or select one from the list of recent files.




3. Navigate to Calibration and Config File > Config File.


- Browse and select a configuration file or select one from the list of recent files.



- Navigate to Calibration and Config File > Program Calibration Data (Cheetah SPI).
- Connect Cheetah Adapter to USB port on PC and SPI port on EVM.
- Click Verify and Program.




- The error message shown above will appear. Since we have not programmed the Flash yet, we expect this error. Press "Yes."



9. Once programming is complete, power cycle the system. When the system restarts it will use the newly programmed calibration and configuration data.

10. Click Close.


5.5 Programming Application Flash




The application flash memory connected to the DLPC120 contains the commands necessary for the DLPC120's initialization and much of its other functionality. The flash image version loaded on the application flash must match the configuration file version loaded on the Piccolo.

This section requires the Total Phase Cheetah and the SPI adapter cable included with the EVM.

Follow these instructions to Program the SPI Flash:



1. Connect Cheetah Adapter to USB port on PC and SPI port on EVM.



2. Navigate to System Configuration > Programming – ASIC Flash > SPI Flash Program (Cheetah SPI).
3. Click Switch SPI Bus.



4. Click Browse and select .cfg file that is programmed on the Piccolo.
5. Click Erase + Program + Verify.
6. When programming is complete, power cycle the system.

IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ("TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products (<http://www.ti.com/sc/docs/stdterms.htm>), [evaluation modules](#), and [samples](http://www.ti.com/sc/docs/sampterm.htm) (<http://www.ti.com/sc/docs/sampterm.htm>).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2018, Texas Instruments Incorporated