



Rework Instruction

- 1) Remove R337 which is on the top of the board.
- 2) Connect a wire from the left pad of R337 as shown above.
- 3) Feed the other end of the wire through the mounting hole near the DSP to the bottom of the board.
- 4) Turn the board over and remove R249.
- 5) Connect the other end of the wire to the right pad for R249. Note that this is the right pin as you are looking at the board.

