



Note: analog section carefull here

NOTE : CHECK 10K POT PIN WHILE PCB DESIGN

|                            |                            |              |
|----------------------------|----------------------------|--------------|
| <b>GANNET TECHNOLOGIES</b> |                            |              |
| <b>BMWS_AD</b>             |                            |              |
| Title                      |                            |              |
| Size B                     | Document Number<br>GI-1900 | Rev<br>1.0   |
| Date:                      | Monday, June 17, 2013      | Sheet 1 of 1 |