



Note:  
 1. Place C16 close to Connector P3.  
 2. Place C17 close to Connector P2.

|                         |                           |       |        |
|-------------------------|---------------------------|-------|--------|
| Title                   |                           |       |        |
| USB-REDRIVER-EVM INT038 |                           |       |        |
| Size                    | Document Number           | Rev   |        |
| B                       |                           | A     |        |
| Date:                   | Wednesday, March 09, 2016 | Sheet | 1 of 1 |