

Change R77 to adjust boost Vout
Change R78 to adjust buck Vout

HV Port

LV Port

Solder a copper strip to the two exposed pads beside D3 on the bottom side of the PCB.

Install 50k at R4

Right position for Boost
Left position for Buck

