



#### Q3, Q4, Q7, Q8, Q9, HS1, HS2, HS3 Assembly Drawing

1. Are to be put inserted into thermal pad tubes per drawing
2. Metal tab of these TO-220 FETs is to be isolated from heat through thermal pad tube
3. Note be careful not to short the FET drain tab to the heat sink.
4. Max Clips are used to attach FETs and thermal pads to the heat sinks

