



- ① Qs 5 Vds waveform test @ 12VDC 3p. o/p = 12V/1A
- ② US1, Qs1, Qs2 ckt Replace by a 3A 100V schottky Diode
- ③ Qs Rson change to 10mΩ, add a jump wire to R16. U2's ckt not use.

Title			
Size	Number	Revision	
A4	A060BCV-PCB1	V3	
Date:	2019/1/23	Sheet of	
File:	D:\My file\A060BCV-PCB1 V3 1213.SchDoc		