

# Fast PMOS Constant Current High Side Switch

**.ic v(hold\_up\_cap) = 8**

```
.include C:\Users\gary\Documents\20_LTspice\0000_Models\irf6218s_I.lib
.ic v(out) = 0
.tran 0 200m 0 50n
```

Gary Davies  
 Lion@palmbeach.freemove.co.uk  
 www.GoatElectronics.com

