



$R2 = R414$
 $Rs1 = (R410 + R407)$
 calculated from datasheet instead of TI's calculator.
 $Rs1$ is divided into two resistors to form a Zener current limit.

$R403$ is used as a place holder to cross regulation and for dummy loading when flyback is used in very light load application

Title: HP-Safe		Revision: V1
Sheet Name: Flyback_28730.SchDoc		Size: A3 Sheet 24 of 25
Date: 02-04-2024	Designer: DR	Reviewer: RS

