

Change R77 to adjust boost Vout

+
50V Output
-

+
12V
-

Solder a copper strip
to the two exposed
pads beside D3 on
the bottom side of
the PCB.

Install 50k
at R4

