

Power Vin can be as low as 1.5V. Add 3.3V on Vin pin.

FSW must be connected to SW. Use Power Vin to calculate the Switching Frequency.

It's constant-off time control and switching frequency will change with Vin.