# **CC256x Production Line Testing Guide**

Return to CC256x Main Wiki

# **Contents**

#### Introduction

#### **Connection-less Tests**

Receiver Test

HCI\_VS\_DRP\_Read\_BER\_Meter\_Result (0xFD13) parameters Example on how to read the results of the test

#### **Connection-Oriented Tests**

Transmitter Test

Receiver Test

# Introduction


These tests are used at the production line after designing the board with the CC256x Bluetooth device. This is to sanity check the board works properly and detect any major design issues and manufacturing defects. For each of the tests on this page there are three formats of instructions given. The first is a generic pseudo code, the second are the parameters to pass to HCI\_Send\_Raw\_Command() in the Bluetopia stack with a micro-controller and the third is the Linux equivalent using either hcitool or SS1Tool which have the same syntax and so are interchangeable.

# **Connection-less Tests**

### **Receiver Test**

The connection-less PLT is a bit error rate (BER) test of the DUT. It is primarily for testing of BT sensitivity (-70dBm per BT standard).

Note: Observe maximum RF input power during PLT test (-5dBm for BR and -10dBm for EDR).



 $The VS \ HCI \ commands \ for the PLT \ test \ mode \ are \ below. \ See \ [HCI \ VS \ Commands \ (http://processors.wiki.ti.com/index.php/CC256x\_VS\_HCI\_Commands\#HCI\_VS\_DRPb\_BER\_Meterror \ (http://processors.wiki.ti.com/index.php/CC256x\_VS\_DRPb\_BER\_Meterror \ (http://processors.wiki.ti.com/index.php/CC256x\_VS\_DRPb\_BER\_Meterror \ (http://processors.wiki.ti.com/index.php/CC256x\_VS\_DRPb\_BER\_Meterror \ (http://processors.wiki.ti.com/index.php/CC256x\_VS\_DRPb\_BER\_Meterror \ (http://processors.wiki.ti.com/index.php/CC256x\_VS\_DRPb\_BER\_Meterror \ (http://processors.wiki.ti.com/index.php/CC2$ r Start .280xFD8B.29)] for more info on syntax.

HCI VS DRPb BER Meter Start 0xFD8B, 0. 0. 0x123456781234, 1. 0x1, 27, 1000, 0x1FF, 0x1

Command OGF = 0x3f:

Command\_Data = [0x00, 0x00, 0x34, 0x12, 0x78, 0x56, 0x34, 0x12, 0x01, 0x01, 0x1B, 0x00, 0xE8, 0x03, 0xFF, 0x01, 0x01];
Command\_Length = 17;

#:/SS1Tool cmd 0x3f 0x18B 0x00 0x00 0x34 0x12 0x78 0x56 0x34 0x12 0x01 0x01 0x1B 0x00 0xE8 0x03 0xFF 0x01 0x01

Delay 5000 (ms)

HCI VS DRP Read BER Meter Result 0xFD13

```
Command_OGF = 0x3f;
Command_OCF = 0x113;
Command_Data = [0x0]; // not used but just define a single byte
Command_Length = 0;
#./SS1Tool cmd 0x3f 0x113
```

The procedure is to send the first VS HCI command (HCI\_VS\_DRPb\_BER\_Meter\_Start) which starts the BER function in the CC256x device. A delay equal to or longer than the time it takes to read the number of packets specified is needed before the second VS HCI command (HCI\_VS\_DRP\_Read\_BER\_Meter\_Result is sent to read back (event) the BER test result.

The parameters of the first command (HCI\_VS\_DRPb\_BER\_Meter\_Start) can be found here.

```
The frequency channel, BD address, packet type and #bytes/packet must match that of the transmitter.
```

### HCI\_VS\_DRP\_Read\_BER\_Meter\_Result (0xFD13) parameters

- Finished at least one test This value will latch and remain high once the designated number of packets are received as specified by the HCI\_VS\_DRPb\_BER\_Meter\_Start 0xFD8B "Number of packets" field.
- Number of packets received This is the current count of the number of packets received for the current iteration of test. This number will roll over once the "Number of Packets" threshold is hit.
- Total bits counted This is the total number of bits received.
- Number of errors found Of the current bits counted, this is the number of errors that were received.

#### Example on how to read the results of the test

The command is: HCI\_VS\_DRP\_Read\_BER\_Meter\_Result oxFD13

It does not have any parameters.

After sending the HCI\_VS\_DRPb\_BER\_Meter\_Start (assuming number of packets is 1000) command, read the results using HCI\_VS\_DRP\_Read\_BER\_Meter\_Result command.

Given below are actual example of a sample run. The parameters to validate if one cycle has completed is "Finished at least 1 test". It will increase sequentially upon completion of each cycle (1000 packets in this example)

### First execution of HCI\_VS\_DRP\_Read\_BER\_Meter\_Result

```
Finished at least 1 test : 0x00
Number of packet received in current measurement : 0x000000a2
Total bits counted : 0x00000000
Number of bits error found : 0x00000000
```

#### Second execution

```
Finished at least 1 test : 0x00
Number of packet received in current measurement : 0x00000148
Total bits counted : 0x00000000
Number of bits error found : 0x00000000
```

### Third execution - Now there is a valid result !!!

```
Finished at least 1 test : 0x01
Number of packet received in current measurement : 0x000000b6
Total bits counted : 0x00000049e
Number of bits error found : 0x00000000
```

Note: Finished at least 1 test : 0x01 ---> after we receive 1000 packets

Note: Number of packet received in current test: 0x000000b6 is no longer relevant for the test which is completed.

If another CC256x unit is used for the BT transmitter in the PLT BER test, then the following two commands needs to be sent after the successful loading of the BT service pack:

```
HCI_VS_Write_BD_ADDR 0xFC06, "123456781234"
HCI_VS_DRPb_Tester_Packet_TX_RX 0xFD85, 3, 0, 0xFF, 0x1, 0x5, 0, 27, 9, 1, 0x01FF
```

```
Command_OGF = 0x3f;
Command_OCF = 0x0006;
Command_Data = [0x34, 0x12, 0x78, 0x56, 0x34, 0x12];
Command_Length = 6;
```

```
Command_OGF = 0x3f;
Command_OCF = 0x185;
Command_Data = [0x03, 0x00, 0xFF, 0x01, 0x03, 0x00, 0x1B, 0x00, 0x0F, 0x01, 0xFF, 0x01];
Command_Length = 12;
#./SS1Tool cmd 0x3f 0x0006 0x34 0x12 0x78 0x56 0x34 0x12
#./SS1Tool cmd 0x3f 0x0185 0x03 0x00 0xFF 0x01 0x03 0x00 0x0F 0x01 0xFF 0x01
```

where the first VS HCI command sets the BD address of the TX device, as the DUT device needs to know the specific BD address of the transmitter. The second VS HCI command | HCI\_VS\_DRPb\_Tester\_Packet\_TX\_RX (http://processors.wiki.ti.com/index.php/CC256x\_Testing\_Guide#Packet\_TX\_2FRX) sets the transmitter characteristics.

The other unit can be any golden unit which has been fully characterized including the CC256x. Also some testers that can be used to carry out this test include the LitePoint IQ2010 (htt p://www.litepoint.com/Products/Test-Systems/IQ2010.html#%7C) and Agilent N4010A (http://www.testequipmentconnection.com/32821/Agilent\_N4010A.php?gclid=CImG1-O1u7c CFUlo7AodlhoA9Q%7C).

### **Transmitter Test**

Refer to Continuous TX in CC256x Testing Guide

# **Connection-Oriented Tests**

The following subset of the BT SIG RF testing is recommended.

### **Transmitter Test**

TRM/CA/01/C Tx Output Power - Low, Mid and High Channels TRM/CA/08/C Initial Carrier Frequency - Low, Mid and High Channels

# **Receiver Test**

RCV/CA/07/C EDR Sensitivity - Low, Mid and High Channels

| {{ 1. switchcategory:MultiCore  For technical support on MultiCore devices, pleas post your questions in th C6000 MultiCore Forum  For questions related to the BIOS MultiCore SDK (MCSDK), please use th BIOS Forum  Please post only comments relat to the article CC256x Producti Line Testing Guide here. | e questions in the C6000 MultiCore Forum For questions related to the BIOS MultiCore SDK (MCSDK), please use the BIOS Forum  ed Please post onloan comments related to the | please post technical your support on questions on The post your C2000 questions of Forum. The DaVin Please post Forum. Ple only post only comments about the article article CC2 y CC256x Production x Line Guide here | support on MSP430 please post your questions on The MSP430 ase Forum.  Please post on OMAP please post your questions on The OMAP please post only comments about the article CC256x article CC256x arg Production Line Testing | support on please post OMAP please your post your questions on on The questions at The OMAP MAVRK http://e2e.ti.com/e Please post only Please post only Please post comments about the comments about the resting Guide |
|---|--|---|---|---|
|---|--|---|---|---|

# Links



Amplifiers & Linear Audio Broadband RF/IF & Digital Radio

Broadband RF/IF & Digital Radio
Clocks & Timers
Data Converters

Data Converters

Logic
Power Management

Processors

ARM Processors

Digital Signal Processors (DSP)

Microcontrollers (MCU)

OMAP Applications Processors

Switches & Multiplexers

Temperature Sensors & Control ICs

Wireless Connectivity

Retrieved from "https://processors.wiki.ti.com/index.php?title=CC256x\_Production\_Line\_Testing\_Guide&oldid=234635"

DLP & MEMS

High-Reliability

This page was last edited on 17 May 2018, at 16:08.

Content is available under Creative Commons Attribution-ShareAlike unless otherwise noted.