

REVISIONS			
REV	DESCRIPTION	DATE	APPROVED
1.00	Added R35 for DRDY input on ADC	08/29/16	WJK
1.01	Changed R108 to 10K, R26 to 510K	10/25/16	WJK

GENERAL Note

Keep resistors going to gates of MOSFET's close to the MOSFET.


Keep associated parts close. Ground traces surrounding and underneath input path. R10 to be close to pin 9 R1 to be close to Q1

Z1 and Z2 should have large traces to ground and Vdd and close to the connector. R15, R19, R20 should be close to the connector and Z1, Z2.

C102-C104, C21 should be placed close to the connector JP1

Create a small heat sink for the drain of Q101

Create a small heat sink for the drain of Q103

		Title Endora Commercial HVAC	
Size B	PCB Number 200-11264-00	Rev 1.01	
Date 10/26/2018	Drawn by WJK		
Filename Endora HVAC Analog.SchDoc	Sheet 2	of 3	