


Assumed Input Structure of DS26C32AM Receiver



--- Current Flow to VDD
(When DS26C32AM is unpowered)

