



Changing RAM Size for CCS and IAR

September 9, 2013




Louisville, KY

www.stonestreetone.com


IAR

a) Right Click on SPPLEDemo-Debug. Select options



b) From (Options for node "SPPLEDemo") window select C/C++ Compiler -> Preprocessor.


f) Select BTPS_MEMORY_BUFFER_SIZE=3600. Now you can change its value




g) Select OK

CCS

a) Select project from CCS Edit – Code Composer Studio window. Then select Properties.



b) From (Properties for “SPPLEDemo”) window select Build -> Advanced Options -> Predefined Symbols.



c) Select BTPS_MEMPRY_BUFFER_SIZE=3600. Now you can change its value

h) Select OK.