



Output pins on side 1 are enabled when EN1 is high or open and in high-impedance state when EN1 is low

- Note:
- i. 5V power is Isolated
 - ii. 12V supply is Not Isolated and taken directly from external device