



In "Serial Port Configuration," I set it as shown below and clicked the OK button.



The configuration screen of the mmWave Demo Visualizer.



Check the configuration of the Device Manager.

