




internal pulldown
0 = Individual power control supported when power switching is enabled

1 = Power control gangs supported when power switching is enabled

GANGED_HS_UP R557 1K-1%-R2 R0402

internal pulldown
0 = Power switching and overcurrent inputs supported

1 = Power switching and overcurrent inputs not supported


FULLPWRMGMTZ R563 1K-1%-R2 R0402

SMBUSZ
HUB_SCL
HUB_SDA
default set smbus


0 = PWRCTL polarity is active low

1 = PWRCTL polarity is active high

PWRCTL_POL_TDO R568 @1K-1%-R2 R0402



OVERCUR4Z R561 10K-1%-R2



internal pullup

1 = I2C mode selected

0 = SMBus mode selected

SMBUSZ R567 1K-1%-R2 R0402

internal pullup

1 = Automatic mode is disabled

0 = Automatic mode is enabled

AUTOENZ R569 1K-1%-R2 R0402

internal pullup

On Board EEPROM

