


RS-422 connection circuit



※In the case of backplane connection, the GND of board-A and board-B are not connected.

※In the case of cable connection, the GND of board-A and board-B are not connected.