





Figure 7. Cold Start V_{CC} Ramp up to EN

t_{VCC} means the time at V_{CC} supply has reached the minimum operating voltage, right?

t_{en} means the time at the EN input Low to High, right?



When the customer are using GPIO for control the EN, does it need this capacitor?

Figure 9. EN Input From Active Controller