



Question
 Please tell me the input voltage value necessary to turn off the output. How small input voltage?

Input Voltage Point-A

Question
 When Input Voltage of Point-A is 0.7V, is the output of ULN2003APWR OFF?

(Power Supply 5V)