


# Understanding the answer received from Mitch M

example) uCOM



Is it correct to understand that the ina2xx driver is a driver for accessing the ADC (INA220AIDGSR) from the external device's CPU, etc.?  
(ina2xx. driver = Source code that runs on Linux)

## re-question

Does the ADC (INA220AIDGSR) have a built-in CPU and memory?  
Is there software inside the ADC to control the CPU?  
Are you using OSS for that software?