


To generate the .TXT firmware file

CCS



type: none text

- ▶ Resource
- General
- ▲ Build
  - ▲ MSP430 Compiler
    - Processor Options
    - Optimization
    - Include Options
    - ULP Advisor
    - Advice Options
    - Predefined Symbols
  - ▶ Advanced Options
  - ▶ MSP430 Linker
  - ▲ MSP430 Hex Utility
    - General Options
    - Diagnostics Options
    - Output Format Options**
    - Load Image Options
    - Additional Array Format Options
  - Debug
  - Project Natures

### Output Format Options

Configuration: **Debug [ Active ]** Manage Configurations...

Array output format (--array)

Output format

- Output ASCII hex format (--ascii, -a)
- Output Intel hex format (--intel, -i)
- Output Motorola S hex format (--motorola, -m=1)
- Output Motorola S hex format (--motorola, -m=2)
- Output Motorola S hex format (--motorola, -m=3)
- Output Extended Tektronix hex format (--tektronix, -x)
- Output TI-Tagged hex format (--ti\_tagged, -t)
- Output TI-TXT hex format (--ti\_txt)**

[Show advanced settings](#) Apply and Close Cancel