


How to save the flash contents of a LF240xA device using CCS3.3

- On CCS 3.3 window Click File> Data > Save



- After clicking “Save” it will ask you for the file destination name and file extension format you want to save (COFF, HEX, DAT).
- After setting the destination path, it will prompt you about the Flash starting address and the size of the array. Click okay and you are done.

