


CH1:VIN:24V



CH2:VOUT:3.3
V

CH3:ON/OFF




① SW=ON/OFF

A large Overshoot occurs



[ON / OFF] It occurs when there is noise in the pin

②Function Generator



No problem occurs