



CURRENT CONTROL

电流反馈



到ADC采样

电流设置



反馈回LM5170

Buck Mode:0-2.3V
Boost Mode:0-0.89V

Title		
Size	Number	Revision
A4		
Date:	2022/3/15	Sheet of
File:	D:\拜特锂电池\CURRENT CONTROL\Doc\B2.SCHDOC	