



PWM PIN CONFIGURATION					
FUNCTION	R4	R1	R3	R2	C1
UnderVoltage Lockout	Mount	Unmount	Mount	Mount	Mount
External supply Enable	Unmount	Mount	Mount	Unmount	Mount
Microcontroller Enable	Unmount	Unmount	Unmount	Mount	Mount

COFF pin configuration					
FUNCTION	RL1	RS	RL0	CS	D1
PWM, Analog Dimming	Mount	Unmount	Unmount	Mount	Unmount and short
Shunt FET Dimming	Unmount	Mount	Mount	Mount	Unmount
PWM, Analog, Shunt FET Dimming	Mount	Mount	Mount	Mount	Mount

Plotted Date : 23/07/07 16:48:33

