



12V SUPPLY

2.98V output at 36V input
 USE TO READ VIN VOLTAGE
 0.66V output at 8V input

3.3V SUPPLY

5V SUPPLY

Power Headers

