



EXCEPT 3.3VSTB ALL POWER RAILS COME UP AT THE SAME TIME. 3.3V MUST NOT COME UP BEFORE 1.8V (PM40100 DEVICE SPEC)