



EN-pin=GND.
When Power Save mode is enabled "PS=GND", does this reverse not occur?