

○ Stress is applied to the package from above.  
In this case, please tell me how many newtons(N) the package can accept.

