



TEXAS  
INSTRUMENTS

TUSB1046EVM

INT053 Rev F

A1 SW2  
3.3V RESET


D1  
C1  
D2 R1  
5V\_IN

JMP4 1KPU E01 1KPD  
JMP3 1KPU E00 1KPD  
JMP8 1KPU DPE01 1KPD  
JMP2 1KPU I2CEN 1KPD  
JMP6 1KPU SSE01 1KPD  
JMP7 1KPU DPE00 1KPD  
JMP9 DCI\_CLK/HPDIN GND  
JMP10 DCI\_DAT GND

D4 C26 R74  
D5 R76  
U1

DP\_PWR  
3P3\_VCC  
JMP1

C2  
C3



R41 R44 R53 R54 R52 C15 R51 C18  
U9 TP56S9970 DH T1 2AU WQFH GA  
R40 R42 R39 R43 R45 R46 R47 R48 R49 R50 R55  
R60 R61 R62 R58 R57 R56  
R71 R68 R67 R70 R69

R2 R3 C8 C9 C10 C11 R5 R6

U3 U4 U5  
D3

3P3\_VCC  
CTL1 GND  
J1

3P3\_VCC  
CTL0 GND  
J2

3P3\_VCC  
FLIP GND  
J3

HRESET  
A1 SW1

JMP12 I2C2\_SDA GND  
JMP11 I2C2\_SCL GND  
R66 R65 R63 R64  
C22

SPI PROGRAMMING

