




1. Motor Current waveform(normal)



PHASE A




PHASE B



2. MOTOR CURRENT WAVEFORM (FAULT PIN ENABLE)

PHASE A



PHASE B

