



DRV8884 **not change** to correct position by first clock

DIR=0



Not change from position 2 (1/2step) to position 4 (full step)



Not change from position 8 (1/2step) to position 3 (full step)



Not change from position 4 (1/2step) to position 1 (full step)




The number of the position is using the number listed in the Figure 3. on the datasheet.


DRV8884 change to **correct** position by first clock

DIR=0



Change from position 1 (1/2step) to position 4 (full step)



Not change from position 3 (1/2step) to position 1 (full step)



Change from position 7 (1/2step) to position 3 (full step)



The number of the position is using the number listed in the Figure 3. on the datasheet.