



ALL SMA CONNECTORS TO FLUSH TO THE EDGE OF THE BOARD, NO GAP ALLOWED.
This is especially critical for: RfOutAP, RfOutAM, RfOutBP, and RfOutBM SMA connectors
Install SMA connectors only per manufacturer's instructions.



ZZ1 ■Install label in silkscreened box after final wash. Text shall be 8 pt font. Text shall be per the Label Table in the PDF schematic.
ZZ2 ■These assemblies are ESD sensitive, ESD precautions shall be observed.
ZZ3 ■These assemblies must be clean and free from flux and all contaminants. Use of no clean flux is not acceptable.
ZZ4 ■These assemblies must comply with workmanship standards IPC-A-610 Class 2, unless otherwise specified.

COMPONENTS MARKED 'DNP' SHOULD NOT BE POPULATED.
ASSEMBLY VARIANT: 004
ORDERABLE: LMX2572LPEUM

PCB VIEWED FROM TOP SIDE	BOARD #: SU601308	REV: C	SUN REV: Not In VersionControl
	TID #: N/A		
PLOT NAME = Top Assembly Drawing	GENERATED : 10/6/2021 5:43:44 PM		TEXAS INSTRUMENTS



COMPONENTS MARKED 'DNP' SHOULD NOT BE POPULATED.
 ASSEMBLY VARIANT: 004
 ORDERABLE: LMX2572LPEUM

PCB VIEWED FROM BOTTOM SIDE	BOARD #: SU601308	REV: C	SUN REV: Not In VersionControl
	TID #: N/A		
PLOT NAME = Bottom Assembly Drawing	GENERATED : 10/6/2021 5:43:46 PM		TEXAS INSTRUMENTS