


MSO-X 3024A, MY51360381: Tue Oct 03 02:50:14 2017




Cursors Menu

Mode
Off

To turn on cursors, press the [Cursors] key on the front panel.

MSO-X 3024A, MY51360381: Tue Oct 03 03:06:19 2017



Cursors Menu

Mode
Manual

Source
<None>

Cursors
X1

Units
 \downarrow

X1: -14.000000us
X2: -186.000000us