

## TPA3138D2 PLIM @1SPW mode



Start saturation



Increase input signal voltage more. It is not saturated output.