



Boot Configuration

AM335X_LCD_DATA[15:0]	0100XXXXXXXX110111b	MMC0, SPI0, UART0, USB0
AM335X_LCD_DATA[15:0]	0100XXXXXXXX111100b	BOOT_SEQ = MMC1, MMC0, UART0, USB0

[15:14]=01=24MHz
 [13:12]=00=Normal Operation
 [5]=1=CLKOUT1 Enabled
 [4:0]=11100=BOOT_SEQ = MMC1, MMC0, UART0, USB0

