USB descriptor	Operating System	Audio		Volume controls		HID Consumer									<b>HID Keyboard</b>	<b>HID Mouse</b>
		Ch Out	Ch In	OUT	IN	O Vol Mute	O Vol +	O Vol -	I Vol Mute	Play/Pause	Skip fw	Skip rev	Fast fw	Rewind	•	
Standard output	Windows XP x32	2	N/A	OK	N/A	OK	ОК	OK	N/A	OK	OK	OK	OK*	OK*	ОК	OK
·	Windows 7 x64	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	2	N/A	ОК	N/A	ОК	ОК	OK	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
Standard output 24 bit	Windows XP x32	2***	N/A	OK	N/A	ОК	OK	OK	N/A	ОК	OK	OK	OK*	OK*	OK	OK
	Windows 7 x64	2	N/A	ОК	N/A	ОК	ОК	OK	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
Standard headset	Windows XP x32	2	1	OK	ОК	OK	OK	OK	No	OK	OK	OK	OK*	OK*	OK	ОК
	Windows 7 x64	2	1	ОК	ОК	ОК	ОК	ОК	No	ок	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	2	1	ОК	ОК	ОК	ОК	ОК	No	ок	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	2	1	ОК	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	2	1	ОК	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
HT1 headphone	Windows XP x32	2	N/A	OK	N/A	No	No	No	N/A	ОК	OK	OK	OK*	OK*	OK	OK
	Windows 7 x64	2	N/A	ОК	N/A	ОК	OK	OK	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)		Not suppo	rted by Mac OS X 1	0.7.2	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	2	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
HS1 headset	Windows XP x32	2	1	OK	OK	No	No	No	No	ОК	OK	OK	OK*	OK*	OK	OK
	Windows 7 x64	2	1	ОК	ОК	ОК	ОК	OK	No	ок	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	2	1	ОК	ОК	ОК	ОК	ОК	No	ок	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)		Not suppo	rted by Mac OS X 1	0.7.2	ОК	ОК	ОК	No	ок	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	2	1	OK	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
Quadraphonic output	Windows XP x32	4	N/A	OK	N/A	OK	OK	OK	N/A	ОК	OK	OK	OK*	OK*	OK	OK
	Windows 7 x64	4	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	4	N/A	ОК	N/A	ОК	ОК	ОК	N/A	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	4	N/A	ОК	N/A	ОК	OK	OK	N/A	ОК	OK	OK	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	4	N/A	ОК	N/A	ОК	OK	OK	N/A	ОК	OK	OK	OK*	OK*	ОК	ОК
Mono microphone	Windows XP x32	N/A	1	N/A	ОК	OK	OK	OK	No	ОК	OK	OK	OK*	OK*	OK	ОК
	Windows 7 x64	N/A	1	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	N/A	1	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	N/A	1	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	N/A	1	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
Stereo microphone	Windows XP x32	N/A	2	N/A	OK	OK	OK	OK	No	ОК	OK	OK	OK*	OK*	OK	OK
	Windows 7 x64	N/A	2	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	N/A	2	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	N/A	2	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	N/A	2	N/A	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	OK
Dual headset	Windows XP x32	2	2	ОК	ОК	ОК	ОК	OK	No	OK	OK	OK	OK*	OK*	OK	ОК
	Windows 7 x64	2	2	ОК	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Windows 8	2	2	ОК	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК
	Mac OS X Lion 10.7.4 (64-bit)	2	2	ОК	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	OK**	ОК
	Ubuntu 11.10 Linux 3.0.0-12-AMD64	2	2	ОК	ОК	ОК	ОК	ОК	No	ОК	ОК	ОК	OK*	OK*	ОК	ОК

<sup>\*</sup> Function of this button is program specific, some programs use these keys as skip fw and rev.

<sup>\*\*</sup> Mac OS X uses a routine for keyboard layout detection that requires the key right of left shift to be pressed. The routine can be cancelled and keyboard then functions normaly.

<sup>\*\*\*</sup> Windows XP does not support true 24 bit audio on USB. Only the 16 MSBs in the 24 bit sample is used, and the remaining 8 LSBs is either 0x00 or 0xFF.