

Device	3dB Frequency (kHz)
1	10.70
2	10.40
3	10.10
4	10.30
5	10.00
6	10.10
7	10.10
8	10.50
9	10.10
10	10.70
11	10.40
12	9.90
13	10.10
14	10.30
15	10.30
16	10.70
17	10.30
18	10.30
19	10.10
20	10.30
21	10.30
22	10.20
23	9.80
24	10.30
25	10.20
26	10.20
27	10.40
28	10.20
29	10.20

