


TPS2590 Start up characteristic

(1) Test Result


ILIM: 40.2Kohm

IFLT: 49.9Kohm



ILIM: 100Kohm

IFLT: 200Kohm



(2) Question

When ILIM and an IFLT level were changed, the peak value and waveform of the input electric current changed. Why do you change? Please teach the mechanism.