
USB IMAGE DSP
U2
DC5M302
LQFN-46
DS90UB914Q Config
U1
DS90UB914Q
QFN48-0.5
Close to DSP Pin5
Close to Pin2
Serial Flash
U3
25L1006
USON
POWER FOR USB Image DSP
U4
RP114-331
SOT23-5
U5
RP114-181
SOT-23-5
H: Enable
JP1
JP2
CON/USB 5pin
DIP5_1.25MM
USB connector is better to be closed to USB IMAGE SOC.
The traces of DM & DP should be straight, short, and parallel.
Title
<Title>
Size
A3
Document Number
<Doc>
Rev
v3.0
Date:
Wednesday, June 20, 2018
Sheet
1
of
1