



Indicate BoM Revision here

Shunts for JP2 and JP20 should not be installed until instructed in test procedure.

1. Mark the box on the board (located in the bottom left corner of the board) indicating the BoM revision. This can be done with permanent marker or label.
2. **Do not** remove the MMB0 from the ADS1298RECGFE-PDK boards. Add the hardware listed below. These will be shipped as a unit.

MMB0 Rev D 3/4" standoffs (2204)
screws (PMSSS 440 0038 PH)

Label the bag with the appropriate EVM name - **ADS1298RECGFE-PDK**