

LMP91300NPN User's Guide

1.	INTRODUCTION	1
2.	SETUP	1
3.	QUICK START	1
4.	BOARD LAYOUT	3
5.	SCHEMATIC	4
6.	BILL OF MATERIALS	5

1. Introduction

The Texas Instruments LMP91300NPN evaluation board allows a designer to use the LMP91300 in an inductive sensor. The LMP91300SWIFEVM can be used with the LMP91300NPN to program and burn the registers of the LMP91300 using the SWIF (Single Wire InterFace) protocol.

2. Setup

Supply and Ground – Power and ground from the LMP91300SWIFEVM are connected to the right side of the board. See the Board Layout section. If another method besides the LMP91300SWIFEVM is used to power the LMP91300NPN board, the supply must be <36V as D3 is a 36V zener.

Load – A load can be connected to the middle pad on the right side of the board.

LC Tank – The left side of the board has pads for mounting a capacitor and coil to form an LC tank.

3. Quick Start

When a new sensor is being used the registers should be setup using the following procedure. Instructions on how to determine the value to put in each register are described in the Register Information section of the LMP91300 datasheet.

- 1. Set RP_MAX in the OSC_CONFIG_0 register.
- 2. Set PADC_TIMEC and RP_MIN in the OSC_CONFIG_1 register.
- 3. Set RESONATOR MIN FREQ in the OSC CONFIG 2 register.
- 4. Set UNDER_RANGE_SWITCH_EN, OSC_AMP, and RESPONSE_TIME in the OSC_CONFIG_3_INIT and OSC_CONFIG_3_FNL registers. The same values should be written to both registers. Setting OSC_AMP to 4V and RESPONSE_TIME to 6144 should give the most accurate results. Note that the power on default for OSC_AMP is 11:Reserved so OSC_AMP must be changed to either 1V, 2V, or 4V.
- 5. Select the value of the CF capacitor:
 - a. Start with a default value of 10nF for CF.
 - b. Move the metal target far away from the LC tank.
 - c. Connect a scope probe to the INB (pin 21) and CFB (pin 17) pins. Since the CFB pin is very sensitive to capacitive loading, it is recommended to use an active probe. As an alternative, a passive probe with a $1k\Omega$ series resistance between the tip and the CFB pin can be used.

October 3, 2013 LMP91300NPN User's Guide 1



- d. Set the time scale of the oscilloscope so that many periods of the signal on the INA pin can be seen. See Figure 1.
- f. Set the CF capacitor value so that the AC portion of the waveform is about $1V_{PP}$ maximum. Decreasing the capacitor value will make the AC portion of the waveform larger. This signal scales linearly with the reciprocal of the filter capacitance. For example, if a 100pF filter capacitor is used and the signal observed on the CFB pin has a peak-to-peak value of 200mV, the desired 1V peak-to-peak value is obtained using a $200\text{mV} / 1\text{V} \times 100\text{pF} = 20\text{pF}$ filter capacitor. Figure 1 shows the waveforms on CFB and INA and Figure 2 shows the waveforms using a zoomed in horizontal scale. Note that the waveforms on CFB and INA are not a constant amplitude. The waveform on CFB should be adjusted so that the maximum value is 1VPP.
- 6. Set the values in the OUT_CONFIG_INIT and OUT_CONFIG_FNL registers as needed. The same values should be written to both registers.
- 7. Put the sensor at the target distance that the switch is supposed to turn on. Read the PROXIMITY_MSB and PROXIMITY_LSB multiple times. If needed, RP_MAX or RP_MIN can be adjusted up or down one step at a time to determine the combination that gives the most accurate setting for this specific sensor.
- 8. Put the sensor at the target distance that the switch is supposed to turn on. Read the PROXIMITY_MSB and PROXIMITY_LSB multiple times, take an average, and write this value into the DET_H_MSB_INIT and DET_H_LSB_INIT and DET_H_LSB_FNL registers. This value may need to be adjusted.
- 9. Put the sensor at the target distance that the switch is supposed to turn off. Read the PROXIMITY_MSB and PROXIMITY_LSB multiple times, take an average, and write this value into the DET_L_MSB_INIT and DET_L_LSB_INIT and DET_L_LSB_FNL registers. This value may need to be adjusted.




Figure 1. Determining the Value of CF





Figure 1. Determining the Value of CF

2 LMP91300NPN User's Guide October 3, 2013




4. Board Layout



October 3, 2013 LMP91300NPN User's Guide 3



5. Schematic



LMP91300NPN User's Guide October 3, 2013



6. Bill of Materials

Designa		Suppli	Supplier Part	Manufact	Manufacturer Part
tor	Description	er	Number	urer	Number
	CAP, CERM, 0.056uF, 16V, +/-10%,	Digi-			
C2	X7R, 0402	Key	399-4901-1-ND	Kemet	C0402C563K4RACTU
		Digi-			
C3	CAP CER 150PF 50V 5% NP0 0603	Key	478-1177-1-ND	AVX	06035A151JAT2A
	CAP, CERM, 0.1uF, 10V, +/-10%,	Digi-			
C4	X7R, 0402	Key	399-3520-1-ND	Kemet	C0402C104K8RACTU
	CAP, CERM, 0.1uF, 50V, +/-20%,	Digi-			C1005X7R1H104M05
C5	X7R, 0402	Key	445-5933-1-ND	TDK	OBB
	RES 0.0 OHM 1/16W JUMP 0402	Digi-		Vishay-	
C6, C7	SMD	Key	541-0.0JCT-ND	Dale	CRCW04020000Z0ED
		Digike	LNJ347W83RACT-		
D1	LED GREEN RECTANGLE SMD	У	ND	Panasonic	LNJ347W83RA
D3, D4,	Diode, Zener, 36V, 200mW, SOD-	Digi-	MMSZ5258BS-	Diodes	
D5	323	Key	FDICT-ND	Inc.	MMSZ5258BS-7-F
		Mous	726-		
Q1, Q2	Transistor, NPN, 80V, 0.5A, SOT-23	er	SMBTA06E6327	Infineon	SMBTA 06 E6327
R1	NTC, 100kohm, 1%, [0201]			Murata	NCP03WF104F05RL
		Digi-	RNCP0805FTD10K0		
R2	RES, 10k ohm, 1%, 0.25W, 0805	Key	CT-ND	Stackpole	RNCP0805FTD10K0
	RES, 0.604 ohm, 1%, 0.25W,	Mous	660-		
R3	[0805]	er	SR732ATTER604F	KOA Speer	SR732ATTDR604F
U1	LMP91300	TI		TI	LMP91300

October 3, 2013 LMP91300NPN User's Guide 5



FCC Warning

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by TI to be a finished end-product fit for general customer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

EVALUATION BOARD/KIT IMPORTANT NOTICE

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by TI to be a finished end-product fit for general consumer use. Persons handling the product(s) must have electronics training and observe good engineering practice standards. As such, the goods being provided are not intended to be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety and environmental measures typically found in end products that incorporate such semiconductor components or circuit boards. This evaluation board/kit does not fall within the scope of the European Union directives regarding electromagnetic compatibility, restricted substances (RoHS), recycling (WEEE), FCC, CE or UL. and therefore may not meet the technical requirements of these directives or other related directives.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT. SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive.

TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please contact the TI application engineer or visit www.ti.com/esh.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

EVM WARNINGS AND RESTRICTIONS

It is important to operate this EVM within the input voltage range of -0.3 V to 48 V and the output voltage range of 0.9 V to 18 V.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 85° C. The EVM is designed to operate properly with certain components above 60° C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2007, Texas Instruments Incorporated

6 LMP91300NPN User's Guide October 3, 2013



NOTES

October 3, 2013 LMP91300NPN User's Guide

7



IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI. Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices.

Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Produ	ucts
-------	------

Amplifiers amplifier.ti.com **Data Converters** dataconverter.ti.com DSP dsp.ti.com Interface interface.ti.com Logic logic.ti.com Power Mgmt power.ti.com Microcontrollers microcontroller.ti.com **RFID** www.ti-rfid.com Low Power www.ti.com/lpw Wireless

Applications

Audio www.ti.com/audio Automotive www.ti.com/automotive Broadband www.ti.com/broadband Digital Control www.ti.com/digitalcontrol Military www.ti.com/military Optical Networking www.ti.com/opticalnetwork Security www.ti.com/security Telephony www.ti.com/telephony Video & Imaging www.ti.com/video Wireless www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265

Copyright © 2007, Texas Instruments Incorporated