Clock tree architect design report

1. Selected solution details:

1.a. Block diagram:

USER INPUT

100 MHz x1

LMK04832

Input

VCO

2560 MHz

40 MHz x1

LVDS (Out A)

10 MHz x1

LVDS (Out C)

160 MHz x1

LVDS (Out B)

https://webench.ti.com/clock-tree-architect

1.b. Solution details:

Devices	Area (mm²)	BOM price estimate ($)	Jitter (fs rms)	Power (mW)
LMK04832	81.00	14.960	115 Out A: 115 Out C: 115 Out B: 115	739

1.c. Device details:

Devices	Area (mm²)	BOM price estimate ($)	Current (mA)	Power (mW)
LMK04832	81.00	14.960	224	739

1.d. Output details:

Devices	Output	Frequency	Format	Clock count	Jitter (fs rms)	Noise floor (dBc/Hz)	Deterministic phase
LMK04832	Out A: AFE	40 MHz	LVDS	1	115	-159	Yes [1]
	Out C: SYNC	10 MHz	LVDS	1	115	-159	Yes [1]
	Out B: TX	160 MHz	LVDS	1	115	-159	Yes [1]

[1] Requires some settings at device level. Kindly, refer the datasheet.

2. Other solutions:

Devices	Area (mm²)	BOM price estimate ($)	Jitter (fs rms)	Power (mW)
CDCE6214	16.00	2.100	351	172
LMK5B12204	49.00	6.500	125	1145
LMK03318	49.00	6.160	100	1208
LMK03806B	81.00	5.720	100	551
LMK04906B	81.00	5.710	123	637
LMK05318	49.00	8.760	125	1119
LMK04816B	81.00	6.430	123	637

https://webench.ti.com/clock-tree-architect

Devices	Area (mm²)	BOM price estimate ($)	Jitter (fs rms)	Power (mW)
LMK04208	81.00	5.710	200	637
CDCE62005	49.00	4.600	171	908
LMK05028	81.00	14.960	150	818
LMK03000	49.00	6.270	800	521
LMK03200	49.00	7.480	800	521
LMK04821	261.00	29.860	88	604
LMK02000	229.00	28.580	64	459
LMK5C33216	81.00	30.000	200	1535
CDCE72010	261.00	28.660	82	974

3. Required system specifications and parameters:

3.a. Required output details:

Name	Format	Frequency	Clock count	Jitter (fs rms)	Noise floor (dBc/Hz)	Additional specs
Out A: AFE	LVDS	40 MHz	1	1000	-50	-
Out C: SYNC	LVDS	10 MHz	1	1000	-50	-
Out B: TX	LVDS	160 MHz	1	1000	-50	-

3.b. Input details:

One or more of the below inputs or TI oscillators may be used.

Name	Frequency	Clock count	Jitter (fs rms)	Noise floor (dBc/Hz)	Additional specs
Input A	100 MHz	1	25	-	-

3.c. System configuration options:

https://webench.ti.com/clock-tree-architect

Application: Medical
Jitter integration bandwidth: 12 kHz to 20 MHz
Max. number of stages: 5
System features required:
　　　Radiation hardened: Exclude
Solution scoring:
　　　Jitter: Important, Power: Important, Price: Less important, Area: Less important

3.d. External VCO and VCXO computation parameters:

VCO attribute	Value	VCXO attribute	Value
Price ($)	30	Price ($)	20
Area (mm²)	140	Area (mm²)	180
Current (mA)	15	Current (mA)	15
Noise floor (dBc/Hz)	-156	Noise floor (dBc/Hz)	-168
Jitter (fs rms)	50	Jitter (fs rms)	50
Min frequency (MHz)	1	Frequency (MHz)	500
Max frequency (MHz)	10000	Auto pick VCXO frequency	true

https://webench.ti.com/clock-tree-architect

Featured clocks & timing tools

Clock tree architect design tool helps you select the right clocks & timing products to design a clock tree based on user entered output, input and system specifications. Along with the clock tree structure – it provides an approximate metric for power, area, jitter and other system parameters. Users are recommended to use the below tools to help with more accurate in-depth simulations, device programming, loop filter design and configuration.

PLLatinum Simulator Tool (PLLATINUMSIM-SW)

The PLLATINUMSIM-SW simulator tool lets you create detailed designs and simulations of our PLLATINUM™ integrated circuits which include the LMX series of PLLs and synthesizers. Users can design active and passive filters, do detailed simulations of phase noise, purs, lock time and bode plots.

TICS Pro Software (TICSPRO-SW)

The TICS Pro software is used to program the evaluation modules (EVMs) for device numbers with these prefixes: CDC, LMK and LMX. These devices include PLLs and voltage-controlled oscillators (PLL+VCO), synthesizers and clocking devices. Users can program EVMs through USB2ANY interface adaptor or onboard USB interface and export the programming configurations for use in end application. Even without an EVM, TICS Pro is very useful tool in determining and validating register configurations and how to set up the device.

Clocks & timing product portfolio and additional resources

Visit Clocks & timing home page to explore the full product portfolio and additional resources to help you with your designs. Also, checkout TI Precision Labs - Clocks and timing videos to learn more about clocks and timing basics, phase lock loop fundamentals, noise, network synchronizers and design tips.

Technical support

TI E2E™ support forums

Receive fast and reliable technical support from our engineers throughout every step of your design.

Get answers now

https://webench.ti.com/clock-tree-architect

TI clock tree architect design report

https://webench.ti.com/clock-tree-architect

TI clock tree architect design report